


# *MTL5500 Series*

## *isolating interface units*



**Instruction Manual**

**INM5500**





# CONTENTS

<b>1</b>	<b>INTRODUCTION</b> .....	<b>1</b>
<b>2</b>	<b>DESCRIPTION</b> .....	<b>1</b>
<b>3</b>	<b>INSTALLATION</b> .....	<b>2</b>
3.1	<b>Modules – pre-installation</b> .....	<b>3</b>
3.2	<b>Installing columns of isolators</b> .....	<b>4</b>
<b>4</b>	<b>ACCESSORIES</b> .....	<b>5</b>
4.1	<b>MTL5500 power bus - Installation and use</b> .....	<b>5</b>
4.2	<b>MPA5500 AC power adaptor</b> .....	<b>6</b>
4.3	<b>Earth rail and tagging accessories</b> .....	<b>7</b>
<b>5</b>	<b>DX ENCLOSURES</b> .....	<b>11</b>
5.1	<b>Environmental conditions</b> .....	<b>11</b>
5.2	<b>Mounting</b> .....	<b>14</b>
5.3	<b>Accessories in enclosures</b> .....	<b>16</b>
5.4	<b>IS warning label</b> .....	<b>16</b>
<b>6</b>	<b>UNIT DESCRIPTIONS, SETTING-UP AND CONNECTIONS</b> .....	<b>17</b>
<b>6.1</b>	<b>Digital Input modules</b> .....	<b>18</b>
6.1.1	MTL5501-SR - Fail-safe Switch/Proximity detector interface .....	19
6.1.2	MTL5510 & MTL5510B - Switch/Proximity detector interface .....	20
6.1.3	MTL5511 - Switch/Proximity detector interface .....	24
6.1.4	MTL5513 - Switch/Proximity detector interface .....	25
6.1.5	MTL5514 - Switch/Proximity detector interface .....	26
6.1.6	MTL5516C - Switch/Proximity detector interface .....	27
6.1.7	MTL5517 - Switch/Proximity detector interface .....	28
<b>6.2</b>	<b>Digital Output modules</b> .....	<b>29</b>
6.2.1	MTL5521 - Solenoid Alarm driver .....	29
6.2.2	MTL5522 - Solenoid Alarm driver .....	30
6.2.3	MTL5523 - Solenoid Alarm driver .....	31
6.2.4	MTL5523V - Solenoid Alarm driver .....	32
6.2.5	MTL5524 - Solenoid Alarm driver .....	33
6.2.6	MTL5525 - Solenoid Alarm driver .....	34
6.2.7	MTL5526 - Switch Operated Relay .....	35
<b>6.3</b>	<b>Pulse and Vibration modules</b> .....	<b>36</b>
6.3.1	MTL5531 - Vibration Transducer Interface .....	36
6.3.2	MTL5532 - Pulse Isolator .....	37
6.3.3	MTL5533 - Vibration Transducer Interface .....	39
<b>6.4</b>	<b>Analogue Input modules</b> .....	<b>40</b>
6.4.1	MTL5541/MTL5541S - Repeater Power Supply .....	40
6.4.2	MTL5541A/MTL5541AS - Repeater Power Supply .....	41
6.4.3	MTL5544/MTL5544S - Repeater Power Supply .....	42
6.4.4	MTL5544A/MTL5544AS - Current Repeater .....	43
6.4.5	MTL5544D - Repeater Power Supply .....	44
<b>6.5</b>	<b>Analogue Output modules</b> .....	<b>45</b>
6.5.1	MTL5546/MTL5546Y - Isolating Driver .....	45
6.5.2	MTL5549/ MTL5549Y - Isolating Driver .....	46
<b>6.6</b>	<b>Fire and Smoke Interface modules</b> .....	<b>47</b>
6.6.1	MTL5561 - Fire and Smoke Detector Interface .....	47
<b>6.7</b>	<b>Temperature Input module</b> .....	<b>48</b>
6.7.1	MTL5575 - Temperature Converter .....	48
6.7.2	MTL5576-RTD - Temperature Converter .....	50
6.7.3	MTL5576-THC - Temperature Converter .....	51

(continued on next page)

6.7.4	MTL5581 - mV/Thermocouple Isolator . . . . .	52
6.7.5	MTL5582 - mV/Resistance Isolator . . . . .	53
<b>6.8</b>	<b>General modules . . . . .</b>	<b>54</b>
6.8.1	MTL5599 - Dummy Isolator . . . . .	54
6.8.2	MTL5991 - 24V dc power supply. . . . .	55
<b>6.9</b>	<b>PCS45/PCL45USB configurator for MTL temperature converters . . . . .</b>	<b>56</b>
<b>7</b>	<b>FAULT FINDING AND ROUTINE MAINTENANCE . . . . .</b>	<b>57</b>
7.1	Maintenance precautions . . . . .	57
7.2	Fault finding. . . . .	57
7.3	Routine maintenance . . . . .	57
<b>8</b>	<b>BENCH TESTING MODULES . . . . .</b>	<b>58</b>
8.1	Digital Input (DI) modules. . . . .	58
8.2	Digital Output (DO) modules. . . . .	59
8.3	Analogue Input (AI) Modules . . . . .	60
8.4	Analogue Output (AO) Modules . . . . .	63
8.5	Testing the functioning of other modules . . . . .	63
<b>9</b>	<b>APPLICATIONS INVOLVING ZONE 2 AND/OR ZONE 22 HAZARDOUS AREAS . . . . .</b>	<b>64</b>
9.1	Enclosure . . . . .	64

## MTL5500 SERIES PRODUCTS

### WARNING



***This manual has content describing the use and installation of safety equipment. This equipment must be installed, operated and maintained only by trained competent personnel and in accordance with all appropriate international, national and local standard codes of practice and site regulations for intrinsically safe apparatus and in accordance with the instructions contained here.***

### ATEX

If the country of installation is governed by the Essential Health and Safety Requirements (Annex II) of the EU Directive 94/9/EC [the ATEX Directive - safety of apparatus] then consult the following MTL document before installation.

**INA5500** ATEX Safety Instructions for MTL5500 Series modules

### ELECTRICAL PARAMETERS (CSA)

Refer to the certification documentation for the electrical rating of these products.

### CERTIFICATION DOCUMENTATION

The MTL web site <http://www.mtl-inst.com> contains product documentation regarding intrinsic safety certification for many locations around the world. Consult this data for information relevant to your local certifying authority.

### FUNCTIONAL SAFETY

If the MTL5500 products are to be used in functional safety applications check that each module has been assessed for that service and refer to the Safety Manual for details.

### REPAIR

MTL5500 Series products **MUST NOT** be repaired. Faulty or damaged products must be replaced with an equivalent certified product.



## 1 INTRODUCTION

This instruction manual describes the procedures for installing, connecting, checking and maintaining MTL5500 Series isolating interfaces and accessories. The MTL5500 products provide a DIN-rail mounted, intrinsically safe interface to hazardous areas of a process plant.

The individual sections of this manual cover the following topics

- ◆ Section 2 describes the series
- ◆ Section 3 specifies precautions both before and during installation
- ◆ Section 4 describes mounting accessories and the power adaptor
- ◆ Section 5 discusses the DX range of enclosures
- ◆ Section 6 provides relevant technical data
- ◆ Section 7 outlines fault-finding and maintenance procedures
- ◆ Section 8 describes bench test procedures
- ◆ Section 9 provides hazardous-area application information

## 2 DESCRIPTION

MTL5500 Series isolators provide intrinsically safe (IS) communication and signal conditioning for a wide range of hazardous-area devices. Total AC and DC isolation exists between input, output and power supply on separately powered units, and between input and output on loop-powered units. No IS earth is required. DIN-rail mounting and plug-in signal and power connectors simplify installation and maintenance. Units are powered from a 20 to 35V DC supply, or, in some cases, from the signal itself.

The table below lists the modules in the MTL5500 Series range. Refer also to the individual MTL5500 Series data sheets.


Digital Input	Channels	Function
MTL5501-SR	1	fail-safe, solid-state output + LFD alarm
MTL5510	4	switch/prox input, solid-state output
MTL5510B	4	multi-function, switch/prox input, solid-state output
MTL5511	1	switch/prox input, c/o relay output
MTL5513	2	switch/prox input, solid-state output
MTL5514	1	switch/prox input, relay + LFD
MTL5516C	2	switch/prox input, relay + LFD outputs
MTL5517	2	switch/prox input, c/o relay + LFD outputs
Digital Output		
MTL5521	1	loop-powered solenoid driver
MTL5522	1	loop-powered solenoid driver, IIB
MTL5523	1	solenoid driver with LFD
MTL5523V	1	solenoid driver with LFD + voltage control, IIC
MTL5524	1	switch operated solenoid driver
MTL5525	1	switch operated solenoid driver, low power
MTL5526	2	switch operated relay
Pulse & Vibration Output		
MTL5531	1	vibration probe interface
MTL5532	1	pulse isolator, digital or analogue output
MTL5533	2	vibration probe interface
Analogue Input		
MTL5541	1	2/3 wire transmitter repeater
MTL5541A	1	transmitter repeater, passive input
MTL5541AS	1	transmitter repeater, passive input, current sink
MTL5541S	1	2/3 wire transmitter repeater, current sink
MTL5544	2	2/3 wire transmitter repeater
MTL5544A	2	transmitter repeater, passive input
MTL5544AS	2	transmitter repeater, passive input, current sink
MTL5544S	2	2/3 wire transmitter repeater, current sink
MTL5544D	1	2/3 wire transmitter repeater, dual output
Analogue Output		
MTL5546	1	4-20mA smart isolating driver + LFD
MTL5546Y	1	4-20mA smart isolating driver + oc LFD
MTL5549	2	4-20mA smart isolating driver + LFD
MTL5549Y	2	4-20mA smart isolating driver + oc LFD
Fire and Smoke		
MTL5561	2	loop-powered for fire & smoke detectors
Temperature Input		
MTL5575	1	temperature converter, THC or RTD
MTL5576-RTD	2	temperature converter, RTD
MTL5576-THC	2	temperature converter, THC
MTL5581	1	mV/thermocouple isolator for low level signals
MTL5582	1	mV/resistance isolator to repeat RTD signals
General		
MTL5599	1	dummy module

### 3 INSTALLATION

#### Important

- ◆ Make sure that all installation work is carried out in accordance with all relevant local standards, codes of practice and site regulations.
- ◆ When planning the installation of MTL5500 Series isolators it is essential to **make sure that intrinsically safe and non-intrinsically safe wiring is segregated**, and that units are installed as required by a nationally accepted authority or as described in EN 60079-14, ISA RP 12.6 or DIN VDE-165.
- ◆ Check that the hazardous-area equipment complies with the descriptive system document.
- ◆ If in doubt, refer to the certificate/catalogue for clarification of any aspects of intrinsic safety or contact MTL or your local MTL representative for assistance.
- ◆ Make sure the correct hazardous-area connector (field-wiring plug) is plugged into the corresponding isolator. It is recommended that the connector is identified by the same tag number as the matching isolator.

**Figure 3.1:**  
**Dimensions of**  
**MTL5500 package**



Mount all MTL5500 Series isolators on low-profile (7mm) or high-profile (15mm) type T35 (top-hat) DIN-rail to EN50022, BS5584, DIN46277. This is available from MTL, in 1 metre lengths (**THR2** - DIN rail). Install isolators within the safe area unless they are enclosed in approved flameproof, pressurised or purged enclosures and ensure that the local environment is clean and free of dirt and dust. Note the ambient temperature considerations of section 3.1.4.

It is recommended that, in normal practice, the DIN rail should be earthed/grounded to ensure the safety of personnel in the event of a.c. mains (line) power being applied accidentally to the rail.


### 3.1 Modules – pre-installation

#### 3.1.1 Switch settings for operating conditions

Some modules have operating conditions, such as Line-Fault Detection (LFD), Phase Reversal, etc., that can be established by the setting of switches on the unit. The subminiature switches are accessible through an aperture on the side of the module (see Figure 3.2) and can be set in the required positions with, for example, the blade of a small screwdriver.

The switch setting options are always indicated on the side label of the module, but the user may also consult the individual module information in Section 6 of this manual for details.

**Figure 3.2:**  
**Location of**  
**switches**



#### 3.1.2 Relay outputs

Reactive loads on all units with relays should be adequately suppressed. To achieve maximum contact life on all *mechanical* output relays, the load should not be less than 50mW, e.g. 10mA at ≥ 5V DC.

#### 3.1.3 Earth leakage detection

An MTL4220 earth leakage detector can be used with a number of MTL5500 Series units to detect hazardous-area earth faults which can then be rectified without needing to shut down the loop ('no-fail' operation).

**Note:** If the hazardous area signal plug fitted does not have a screw terminal in position 3 then part number 'HAZ1-3' can be ordered and fitted to use this function.

### 3.1.4 Ambient temperature considerations


Ambient temperature limits for unenclosed MTL5500 Series isolators are from  $-20^{\circ}\text{C}$  to  $+60^{\circ}\text{C}$  with units close-packed.

## 3.2 Installing columns of isolators

On new installations, if isolators are mounted in several rows or columns, mount alternate rows or columns so that units face in opposite directions. This allows safe- and hazardous-area wiring looms to be shared. See Figure 3.1 for isolator dimensions.

### 3.2.1 Mounting isolators on DIN rail

**Figure 3.3:**  
DIN rail mounting  
and removal  
of isolators




Clip an isolator onto the DIN rail as shown in Figure 3.3, with the blue signal plugs facing towards the hazardous-area. To remove an isolator from the rail, insert a screwdriver blade (2.5 - 5.0mm diam.) into the clip as shown. This will release the clip so that the isolator may be pivoted off the rail - there is no need to lever the clip. Allow a maximum mounting pitch of 16.2mm for each unit.

### 3.2.2 Wiring up isolators

Each unit is supplied with the appropriate number and type of safe- and hazardous-area connectors (see Figure 3.4), as dictated by the terminals used and the type of power supply.

**Figure 3.4:**  
Removable  
power and  
signal plugs



**Note:** Earth Leakage Detection requires the use of hazardous area connector type HAZ1-3, which may need to be ordered separately. See datasheet for ordering information.

Loop-powered devices do not require power connectors. Depending on the installation, it may be easier to wire up isolators with power and signal plugs either in place or removed. Either way, allow sufficient free cable to permit plugs to be removed easily for future maintenance and/or replacement purposes. See Section 6 for instructions on wiring individual modules.

#### 3.2.2.1 Signal and power conductors

Removable signal and power plugs are fitted with screw clamp terminals. Note that the conductors should be between 14 and 24 AWG (1.6 and 0.5mm diam.) in size. Signal plugs, located on top of the modules, are mechanically keyed to fit in only one position. They are coloured grey, for safe-area connections, and blue, for hazardous-area connections.

For externally powered units, a power plug slots into the socket at terminals 13 and 14 on the safe-area side of each module. The socket is coloured black if the unit is dc powered. Power plugs are coloured grey, for plugging into the black sockets of dc powered units.



### 3.2.2.2 Making connections

- a) Trim back the insulation of conductors by 12mm.
- b) Check the terminal assignments shown in section 6 or on the side label of the unit.
- c) Insert conductors according to the terminal assignments and tighten screws.

If the wires are to be fitted with crimp ferrules, the following is a list of those recommended with required trim lengths for each:

**Table 3.1**  
**Crimp ferrule options**

Plug type	Entry	Wire size (mm <sup>2</sup> )	Metal tube length (mm)	Trim length	Recommended ferrules
Signal	Single	0.75	12	14	Weidmuller 902591
Signal	Single	1.0	12	14	Cembre PKC112
Signal	Single	1.0	12	14	Phoenix Contact AI 1-12 RD (3200674)
Signal	Single	1.5	12	14	Cembre PKE1518†
Signal	Single	2.5	12	14	Cembre PKE2518†
Power	Twin	2x0.75	10	12	Cembre PKET7510
Power	Twin	2x0.75	10	12	AMP (non-preferred) 966144-5
Power	Twin	2x1.0	10	12	Phoenix Contact AI-TWIN 2X 1-10 RD
Power	Single	0.75	10	12	AMP 966067-0
Power	Single	1.0	10	12	Phoenix Contact AI 1-10 RD

† These ferrules with 18mm length metal tubes should be cut to 12mm after crimping

**Note:** Smaller section wire than that stated can often be successfully used if the crimping is good.

**Crimp tool:** Phoenix Contact Crimpfox UD6 part number 1204436

### 3.2.2.3 Finishing

Wire up individual isolators in accordance with wiring schedules. Daisy-chain power supply connections between individual power plugs or use the power bus (see section 4.1).

Segregate hazardous- and safe-area wiring into separate trunking or looms wherever possible to avoid errors and maintain a tidy installation.

Use an MTL5599 dummy isolator to provide termination and earthing for unused cores from the hazardous area.

## 4 ACCESSORIES

### 4.1 MTL5500 power bus - Installation and use

#### 4.1.1 MTL5500 Series power bus

A power bus kit enables power supply terminals (13 and 14) of up to 32 installed MTL5500 Series units to be linked to a standard 24V power supply. The bus consists of a chain of power plugs and different lengths are available to suit various numbers of modules as follows.

**Table 4.1**  
**Power bus kit options**

Number of modules	Kit ID code <small>(contains grey power plugs for 24V dc supply)</small>
1 to 8	PB-8T
9 to 16	PB-16T
17 to 24	PB-24T
25 to 32	PB-32T


#### 4.1.2 Installation

1. Check to make sure the bus length is correct for the number of modules involved.
2. If the number of modules is less than the maximum number the chain will support, cut off the surplus power plugs at the tail end of the chain - leaving sufficient cable to attach further power plugs if it becomes necessary later.
3. Insert power plugs into the power terminals on the safe- area side of each module in sequence.
4. Connect the power supply source to the tail end of the chain (using the insulation displacement connectors [Scotchloks] provided if required).

**Notes:**

1. To avoid excessive voltage drop or over-current, DO NOT connect power buses in series.
2. Surplus sections can be used (and, if required) connected together provided the cut ends are safely terminated and/or connected together. Use single ferrules with a crimp tool or insulation displacement connectors (Scotchloks). Suitable ferrules and connectors are provided with the kits.


**Figure 4.1:  
Power bus  
wiring, joining  
and terminating**



**4.2 MPA5500 AC power adaptor**

When only one or two MTL5500 modules are required for a particular application, it may be desirable to power the units from the AC mains supply directly, rather than use a separate DC supply unit. The MPA5500 is an adaptor that plugs into the DC power socket on the side edge of an MTL5500 module and clips securely onto the module housing. Its 25V DC power output is sufficient to supply a single module and can be connected to any normal ac power source.

**Figure 4.2:  
MPA5500  
AC power  
adaptor**



To fit the adaptor, locate the tongue of the adaptor into the top slot on the side of the MTL5500 module and press the adaptor until it fits closely to the body of the module, as shown.

Use double-insulated AC power cable with conductor parameters of 0.2–1.5mm<sup>2</sup>, or 0.25–1.5mm<sup>2</sup> if using ferrules. Strip the outer insulation by no more than 30mm, then strip the inner conductors by 8mm. Insert the cables appropriately in the cage-clamp connectors marked 'L' and 'N'.

The incoming AC power must have some form of power disconnection device, such as a switch or circuit breaker; a coupler that can be disconnected without the use of a tool; or a separable plug, without a locking device, to mate with an adjacent socket outlet.

In addition, some form of cable anchorage must be used to relieve the cable conductors from strain, including twisting, where they connect to the adaptor, and which will also protect the insulation of the cable from abrasion.

### 4.3 Earth rail and tagging accessories

This section explains how to specify and assemble earth rail and tagging strip accessories for the MTL5500 Series.

The accessories consist of mounting brackets, earth rails, tagging strips and associated parts. They provide facilities for earthing, terminating cable screens and tagging (identifying) the positions of individual units.

#### 4.3.1 Parts list

##### **IMB57 Insulating mounting block (Figures 4.3, 4.4 & 4.5)**

One required at each end of a tagging strip/earth rail. Suitable for low-profile (7.5mm) and high-profile (15mm) symmetrical DIN rail.

##### **ERB57S Earth-rail bracket, straight (figure 4.3, 4.4 & 4.9)**

Nickel-plated bus bar; supplied with two push fasteners, one earth-rail clamp (14mm, 35mm<sup>2</sup>) and one earth cable clamp (10mm, 16mm<sup>2</sup>).

**Note:** ERB57S is the preferred choice of earth-rail bracket. It is usually fitted in the upper slot on insulating mounting block IMB57.

Where the earth rail is required to be positioned at a lower height and to allow access to the IMB57 mounting screws, the straight earth-rail bracket ERB57S can be inserted in the lower slot, but only **after** insulating mounting blocks IMB57 are clamped to the DIN rail. This may not be possible if, for example, trunking is fitted. In this case, fit offset earth-rail bracket ERB570 (see figure 4.4 & 4.10) in the upper slot: the mounting blocks can then be fitted in a restricted space with this bracket already fitted.

##### **ERB570 Earth-rail bracket, offset (figure 4.9)**

Nickel-plated bus bar; supplied with two push fasteners, one earth-rail clamp (14mm, 35mm<sup>2</sup>) and one earth cable clamp (10mm, 16mm<sup>2</sup>).

##### **ERL7 Earth rail, 1 m length (figure 4.9)**

Nickel-plated bus bar; may be cut to length.

##### **TAG57 Tagging strip, 1 m length (figure 4.3, 4.4 & 4.6)**

Cut to size. Supplied with tagging strip label.

##### **TGL57 Tagging strip labels, set of 10 x 0.5m (figure 4.3 & 4.4)**

Spares replacement, for use with TAG57 tagging strip.

##### **MS010 DIN rail module spacer, 10mm, pack of 5 (figure 4.7)**

Grey spacer; Used to provide 10mm air-circulation space between modules, if necessary.

##### **ETM7 Earth terminal, bag of 50 (figure 4.8)**

For terminating cable screens and OV returns on the ERL7 earth rail. For cables ≤ 4mm<sup>2</sup>.

##### **TH5000 Tag holder**

Spares replacement.

#### **Connectors**

Spares replacement: HAZ1-3, HAZ4-6, HAZ-CJC, PWR5000, SAF7-9, SAF10-12 (SAF1-3 and SAF4-6 grey connectors, also available for use in safe-area applications).

#### 4.3.2 Assembly

##### 4.3.2.1 Fitting earth rails

a) *In upper position*

Before fitting insulating mounting blocks IMB57, check that the swing nuts in the base of each unit are turned back into the moulding. Locate the mounting blocks on the DIN rail in the chosen position and tighten the screws (see figure 4.10). Check that the swing nuts rotate correctly to locate underneath the flanges of the DIN rail.

Slide a straight earth-rail bracket ERB57S into the upper slot in each mounting block. Push two plastic push fasteners into each bracket to locate the brackets in the mounting blocks.




Figure 4.3: Assembly drawing showing part numbers




Figure 4.4: Mounting details




Figure 4.5: IMB57 Insulating mounting block




Figure 4.6: TAG57 Tagging strip, 1m length



Figure 4.7: MS010 DIN rail module spacers




Figure 4.9: Earth rails and clamps





Figure 4.8: ETM7 Earth terminals

**Figure 4.10:  
Fitting IMB57**



Cut earth rail ERL7 to the length needed. Slide the required number of ETM7 earth terminals (5mm or 7mm wide) onto the rail. Clamp each end of the earth rail to earth-rail brackets ERB57S using the terminal clamps (14mm, 35mm<sup>2</sup>) supplied. Fit an earth clamp (10mm, 16mm<sup>2</sup>) to the free end of each earth-rail bracket.

**Note:** For lengths of earth-rail greater than 500mm, provide additional support by installing a third IMB57 mounting block and earth-rail bracket, mid-way between the end mounting blocks. Snap out the perforated extension between the lugs on this mounting block if a continuous tagging strip is to be fitted (see figure 4.3).

*b) In lower position, where at least 150mm clearance exists on one side, measured from the edge of the mounting block.*

As for *a)*, but slide earth-rail brackets ERB57S into the lower slots in each mounting block.

*c) In lower position, where there is insufficient clearance to fit earth-rail brackets ERB57S.*

As for *a)*, slide offset earth-rail brackets ERB57O into the upper slot in each mounting block before assembling the mounting blocks to the DIN rail. ERB57S brackets cannot be used because they obscure the fixing screws on the mounting blocks.

#### **4.3.2.2 Fitting tagging strips**

Assemble mounting blocks IMB57 to the DIN rail as above. Cut TAG57 tagging strip and label to the length needed, and insert label so that the appropriate side is visible. Clip the strip onto the lugs on the mounting blocks. Hinge up the strip to provide access to the tops of the isolators.


**Note:** If necessary, provide additional support for long lengths of tagging strip by installing an extra IMB57 mounting block mid-way between the end mounting blocks. Snap out the perforated extension between the lugs on this mounting block.

#### **4.3.3 Completed assemblies**

Figure 4.11 illustrates a complete assembly of MTL5500 isolators using the accessories mentioned above.

The broken-line boxes either side of the assembly represent cable trunking, and the accompanying dimensions represent the recommended minimum spacing between the trunking and the module assemblies.

**Figure 4.11:**  
**MTL5500 Series**  
**complete assembly**



Colour	Module no.	Function
Yellow	MTL5501-SR MTL5504	Digital Inputs
White	MTL551x	
Red	MTL552x	Digital Outputs
Blue	MTL5531/33	Vibration
Purple	MTL5532	Pulse
Blue	MTL5541x MTL5544x	Analogue Inputs
Green	MTL5546x MTL5549x	Analogue Outputs
Blue	MTL556x	Fire & Smoke
Orange	MTL5575 MTL5576 MTL558x	Temperature inputs
Grey	MTL5599	Dummy isolator

**Table 4.2: MTL5500 front label colour coding**

## 5 DX ENCLOSURES

Enclosures are usually selected on the basis of the number of units they will accommodate and Table 5.1 shows the capacity of each of the enclosures. Figure 5.2 shows each type of enclosure containing MTL5500 modules.

**Table 5.1:** DX range of enclosures - module capacities

Enclosure	Number of MTL5500 isolators 16mm mounting pitch
DX070	4 (2*)
DX170	10 (8*)
DX430	26 (24*)

\* Use these figures when two IMB57 mounting brackets for tagging/earth-rail accessories are included.

**Note:** The user should be aware that some workshop preparation may be required for the cable gland plates before the enclosure is ready for on-site installation.

### 5.1 Environmental conditions


Environmental conditions that should be taken into account when installing DX enclosures include:-

	See section
Maximum ambient temperature limits	5.1.1
Storage temperatures	5.1.2
Humidity	5.1.3
Corrosion resistance	5.1.4
Flammability	5.1.5
Impact resistance	5.1.6
Chemical resistance	5.1.7

#### 5.1.1 Maximum outside enclosure temperature limits


The maximum outside enclosure temperature depends upon the total power dissipated by the installed

**Figure 5.1: Graph depicting outside enclosure temperature limits for DX enclosures used with MTL5500 Series isolators**



modules which, in turn, depends upon their number and type. It can also be influenced by the Authority whose standards may need to be applied to the system, e.g. Baseefa, Factory Mutual Research Corporation, Canadian Standards Association.

Figure 5.1 shows, in graphical form, the maximum outside enclosure temperatures ( $T_{MO}$ ) for given levels of power dissipation.



**Figure 5.2: MTL's DX range of enclosures**



The graph was derived from the following equation and should be used to calculate accurately the suitability of any particular mix of modules.

$$T_{MO} = 60^{\circ}\text{C} - \delta T$$


where  $\delta T = k_1 \times P$

P = total power (watts) dissipated by modules in an enclosure

$k_1$  = is a dissipation constant for a given enclosure and module series. Select the relevant value from Table 5.2.

(60°C is the temperature inside the enclosure)

**Figure 5.3: Optimum orientation for wall mounted enclosure**



**Table 5.2:** Dissipation constant  $k_1$  for enclosures (°C/watt)

	<b>DX070</b>	<b>DX170</b>	<b>DX430</b>
MTL5500	4.03	1.88	0.82

Orientation of the enclosures is also important - the optimum position being on a vertical surface with the internal DIN-rail horizontal as shown in Figure 5.3. Any other position can reduce the maximum allowable ambient temperature by up to 5°C.

### Examples

Tables 5.3 and 5.4 list likely combinations of MTL5500 Series modules in the three enclosure types and indicate the acceptable maximum permitted outside enclosure temperature for these based on the graph in Figure 5.1. See the specifications included in the datasheets for the power dissipation figures of individual MTL5500 Series modules.

### 5.1.2 Storage temperatures

Storage temperatures are safe within the range -40°C to +80°C.

### 5.1.3 Humidity limits

Safe humidity limits are within the range 5 to 95% RH.

**Table 5.3:** Typical mix of MTL5500 Series modules

<b>Enclosure</b>	<b>Modules installed</b>	<b>Power dissipation of modules in watts (P)</b>	<b>Maximum outside enclosure temp. (T<sub>MO</sub>) °C</b>
DX070	2 x MTL5511 + 2 x MTL5544	(2 x 0.72) + (2 x 1.4) = 4.24	42.9
DX170	5 x MTL5511 + 5 x MTL5544	(5 x 0.72) + (5 x 1.4) = 10.6	40.1
DX430	13 x MTL5511 + 13 x MTL5544	(13 x 0.72) + (13 x 1.4) = 27.56	37.4

**Table 5.4:** Power versus maximum outside enclosure temperature

<b>Enclosure</b>	<b>Number of installed modules</b>	<b>k °C/watt</b>	<b>Power dissipation of modules in watts (P)</b>	<b>Maximum outside enclosure temp. (T<sub>MO</sub>) °C</b>
DX070	4	4.03	4.0	43.9
	4	4.03	6.0	35.8
DX170	10	1.88	10.0	41.2
	10	1.88	15.0	31.8
DX430	26	0.82	21.6	42.3
	26	0.82	39.0	28.0

### 5.1.4 Corrosion resistance

The effect of corrosion on DX enclosures is negligible.

### 5.1.5 Flammability rating

The flammable properties of the materials used in the construction of the enclosures are well understood by manufacturers and ratings have been established to a number of standards. One of the better known standards is the Underwriter's Laboratory standard UL 94 and the ratings for the enclosure materials are given as:

Materials	UL94 rating
Polycarbonate (all lids)	V2/V0
Polycarbonate with glass reinforcement (DX070 base)	V1/V0
Polyester with glass reinforcement (DX170 & DX430 bases)	V0

Items made from similar materials are well established as suitable for use in process I/O marshalling areas.

### 5.1.6 Impact resistance

The enclosure designs have been tested to an impact resistance of greater than 2 Joules which exceeds the BS EN 61010-1 requirements of 0.5 Joules.

### 5.1.7 Chemical resistance

The overall chemical resistance of the enclosures is limited by the resistance of the transparent polycarbonate lid. The glass-reinforced polycarbonate/polyester (GRP) bases have a higher resistance than plain polycarbonate. Table 5.5 lists qualitative evaluations of resistance to a variety of chemical agents.

**Table 5.5:** Qualitative evaluations of resistance to various chemical agents

Chemical agents	Qualitative evaluation of resistance
Salt water; neutral salts; acids (low concentrations); hydraulic oil	Excellent
Alcohols	Very good
Acids (high concentrations); alkalis (low concentrations); petrol; cooling fluids	Good
Alkalis (high concentrations); solvents.	Poor

## 5.2 Mounting

### 5.2.1 General

These instructions are concerned solely with mounting the DX enclosures. Instructions for wiring and testing individual modules within the enclosures are provided in Section 6.

Sufficient space is provided within the enclosures to accommodate tagging and earth-rail accessories but this is at the expense of a reduction in the number of modules that can be fitted.

### 5.2.2 Location and orientation

#### 5.2.2.1 Location

The DX enclosures are intended for safe (non-hazardous) area use.

The enclosures are rated NEMA 4X; consequently, in N. America or Canada, assuming the modules have the required approvals, they can be used in Class 1, Division 2 (gases) location, but check with local requirements and ensure all cable entries also conform. In this case, an additional warning label will be required on or near the enclosure warning that the MTL5500 interfaces must not be removed unless the area is known to be non-hazardous. The enclosures are NOT suitable for Class II or III, Division 2 hazardous locations.

#### 5.2.2.2 Orientation

As noted earlier (see section 5.1.1), for optimum temperature performance the enclosures should be mounted on a vertical surface with the internal DIN rail horizontal.

### 5.2.3 Mounting details

See Figure 5.2 for the dimensions and mounting hole distances, etc., of the three DX enclosures. The recommended method of mounting-described here-uses the four wall-mounting lugs supplied with each enclosure. An alternative method of mounting is by direct attachment to the mounting surface through the corner holes.

**Note:** When the wall-mounting lugs are used to attach the enclosures, the overall depth of the enclosure is increased by an additional 3.3 mm (DX070) or 7 mm (DX170 and DX430).

- a) At each of the four corner fixing holes, insert one of the screws provided and use it to attach a fixing lug to the base of the enclosure.
- b) Each lug can be used in one of two positions as shown in Figure 5.2.
- c) Attach the lugs to the mounting surface with suitable fasteners.
- d) Diameters of fixing holes in lugs are 5.5mm (DX070) and 7.0mm (DX170 and DX430)
- e) Appropriate fixing hole distances are shown in Figures 5.2.

### 5.2.4 Cable glanding

All cables into the enclosures must be glanded to IP65 standards to maintain this rating for the enclosure as a whole. Cable glands and gland plates are not supplied. Glanding requirements vary for each enclosure as follows:

#### DX070

On the DX070, 'knockout' holes are provided, in two different sizes (15.5 mm and 21 mm), on the side faces of the base. See Table 5.7 for recommended cable glands.

#### DX170

The DX170 can accommodate one gland plate on each side - see figure 5.2 for details. Table 5.6 lists suppliers of suitable gland plate kits and Table 5.7 lists recommended glands.

#### DX430

The DX430 can accommodate two gland plates on each side - see figure 5.2 for details. Table 5.6 lists suppliers of suitable gland plate kits and Table 5.7 lists recommended glands.

**Table 5.6:** Recommended gland plate kits for the DX170 and DX430 enclosures.

Manufacturer/agent	Manufacturer's part number	
	Enclosure DX170	Enclosure DX430
Hellermann Tyton	TL-27/360	TL-27/270
Sarel	21128	21127

**Table 5.7:** Recommended cable glands for use with DX enclosures.

Gland thread size	Cable sizes (mm)	Gland plate hole size (mm)	Weidmuller part nos.		Sarel part nos.	
			Gland	Locknut	Gland	Locknut
PG9	5 to 8	15.2	951891	952216	08871	08881
PG13,5	8 to 13	20.4	951893	952218	08873	08883

Weidmuller (UK) <http://www.weidmuller.co.uk>

Sarel (UK) <http://www.sarel.co.uk>

Hellermann Tyton (UK) <http://www.hellermantyton.co.uk>

### **5.3 Accessories in enclosures**

Apart from mounting, there are some other installation details which should be considered before adding the appropriate interface modules and making the necessary cabling connections.

A range of accessories is available to accompany the MTL5500 units (see section 4) and the following points should be observed.

#### **5.3.1 Insulating mounting block (IMB57)**

A pair of these can be attached to the DIN rail, at either end of the modules, to provide a mounting for earth rails. Use of mounting blocks will reduce the space available for isolator modules.

#### **5.3.2 Earth rails (ERL7)**

Earth rail is produced in 1 metre lengths and will require cutting to length before mounting. ERL7 earth rails can be mounted either side of the modules but are typically mounted on the hazardous side of the DIN rail.

#### **5.3.3 Tagging strip (TAG57 and TGL57)**

Tagging strip is produced in 1 metre lengths and will require cutting to length before mounting. Similarly, the labels will require cutting to fit the tagging strip.

### **5.4 IS warning label**

A 'Take Care' IS warning label is provided inside each enclosure. This should be attached to the inside of the transparent lid when its orientation has been established.

## 6 UNIT DESCRIPTIONS, SETTING-UP AND CONNECTIONS

This section describes the function (briefly), the setting-up procedure and the wiring connections for each MTL5500 Series unit. For a fuller functional description and a detailed technical specification, refer to the individual datasheets, which can be found on the MTL web site at <http://www.mtl-inst.com> or in the current MTL IS catalogue.

If a fault is suspected, first check that the power LED is lit (not applicable to loop-powered devices). If necessary, check that all signal and power plugs are properly inserted, that no wires are loose and that the unit is mounted correctly. If operation is still suspect, the unit should be replaced with a servicable unit.

There are no replaceable parts inside MTL5500 Series units, so any that appear to be inoperative should be returned to the manufacturer/supplier for repair or replacement.



### WARNING

**When disconnecting units for maintenance purposes, take care to segregate hazardous and safe-area cables.**

- **Short circuit hazardous-area cable cores to an IS earth or insulate and secure the ends.**
- **Insulate and secure safe-area cables.**

**If testing a unit 'in situ' note that the test equipment used MUST be intrinsically safe.**

The rest of this section is divided into sub-sections based upon the type of module, as follows.

### 6.1 Digital Input modules

MTL5501-SR, MTL5510, MTL5510B, MTL5511, MTL5513, MTL5514, MTL5516C, MTL5517

### 6.2 Digital Output modules

MTL5521, MTL5522, MTL5523, MTL5523V, MTL5524, MTL5525, MTL5526

### 6.3 Pulse and Vibration modules

MTL5531, MTL5532, MTL5533

### 6.4 Analogue Input modules

MTL5541, MTL5541A, MTL5541AS, MTL5541S, MTL5544, MTL5544A, MTL5544AS, MTL5544D, MTL5544S

### 6.5 Analogue Output modules

MTL5546, MTL5546Y, MTL5549, MTL5549Y

### 6.5 Fire and Smoke interface modules

MTL5561

### 6.7 Temperature Input modules

MTL5575, MTL5576-RTD, MTL5576-THC, MTL5581, MTL5582

### 6.8 General modules

MTL5599, MTL5991

### 6.9 PCS45/PCL45USB configurator for MTL temperature converters

**Note:** Any LED indicator provided on the modules will display in the following colours:

LED label	LED colour
<b>PWR</b> (power)	Green
<b>STS</b> (status)	Yellow
<b>LFD</b> (line fault)	Red
<b>FLT</b> (fault)	Red
<b>OPx</b> (o/p status)	Yellow


## 6.1 Digital Input modules

The Digital Input (DI) module range offers solid state or relay output switches in a safe area that respond to input switches located in a hazardous area. Single or multiple channel (2 or 4) options are available, as well as **Line-Fault Detection (LFD)**.

Modules with LFD can recognise open or short circuit conditions on the input wires going to the field sensors, and some DI modules have the facility to reverse the effect of the input on the output i.e. **phase reversal**.

These options are chosen with switches located on the edge of the module on the hazardous area terminal side. In some applications it may be easier to set these switches *before* fitting the module to the DIN-rail.

**Figure 6.1:**  
**Switches**  
**to set LFD and**  
**phase reversal**



### 6.1.1 Phase reversal

Set the PR switch ON or OFF for the appropriate channel(s).

### 6.1.2 Line-Fault Detection (LFD)

Where fitted, set the LF switch ON or OFF for the appropriate channel(s). **Note:** LFD is permanently active on the MTL5501-SR.

For all DI modules with LFD **except for the MTL5501-SR**; when using the LFD facility with a contact input, resistors must be used. Fit 500Ω to 1kΩ (preferred value 680Ω) in series with the switch and 20kΩ to 25kΩ (preferred value 22kΩ) in parallel with the switch.

For modes of operation of the MTL5510 & MTL5510B that include LFD, resistors should be fitted as described above.

**For MTL5501-SR** use 1k4Ω in series and 10kΩ in parallel with switch contact inputs.

**For hazardous-area inputs conforming to EN 60947-5-6:2001 (NAMUR)**, a line fault is judged by the following rules:

- ◆ Open circuit condition if hazardous-area current <50μA
- ◆ Line integrity (no open circuit) if hazardous-area current >250μA
- ◆ Short circuit condition if hazardous-area load <100Ω
- ◆ Line integrity (no short circuit) if hazardous-area load >360Ω

**Note:** the open circuit window (between 250μA and 50μA), and the short circuit window (between 100Ω and 360Ω), is not hysteresis. All MTL5500 Series modules, with inputs conforming to EN 60947-5-6:2001 (NAMUR), will switch between open and complete circuit conditions within these limits.


The MTL5501-SR LFD relay *de-energises* when a fault condition is detected. The MTL5514 and the MTL5517 *energise* the LFD relay to indicate a fault condition.

### 6.1.3 MTL5501-SR - Fail-safe Switch/Proximity detector interface

#### Single channel, fail-safe module with line-fault detection

The MTL5501-SR enables a fail-safe switch/proximity detector located in the hazardous area to control an isolated fail-safe electronic output. It provides line-fault detection (LFD) alarm contacts and is designed for use with approved fail-safe sensors in loops that require operation up to SIL3 according to the functional safety standard IEC 61508.

**Note:** For reliable, long-term operation the load on the LFD switching relay should be not less than 50mW, e.g. 10mA at 5V DC.



**Figure 6.2:**  
Top label  
for MTL5501-SR

Terminal	Function
1	Input -ve
2	Input +ve
7	Output -ve
8	Output +ve
10	LFD
11	LFD
13	Supply -ve
14	Supply +ve

#### Input / output characteristics

Input value in sensor circuits	Fail-safe output	Operation	LFD contacts
$2.9\text{mA} < I_s < 3.9\text{mA}$	ON	Normal	CLOSED
$I_s < 1.9\text{mA} \ \& \ I_s > 5.1\text{mA}$	OFF	Normal	CLOSED
$I_s < 50\mu\text{A}$	OFF	Broken line	OPEN
$R_s < 100\Omega$	OFF	Shorted line	OPEN

Correct operation of the fail-safe output and LFD is indicated by the LEDs on the front of the unit. The yellow **O/P** LED is ON when the fail-safe output is energised. The red **LFD** LED flashes if a line fault is detected. The fail-safe output is de-energised (OFF) if the module detects an incorrect sensor current, an open circuit or a short circuit in the sensor circuit.

Input signal sensors may be either suitable proximity sensors or switches. The proximity sensor properties are specified in the standard EN60947-5-6:2001; however, when used with MTL5501-SR modules, additional requirements for the "low-impedance" current of  $3.4 \pm 0.5\text{mA}$  must be met. The list below shows suitable proximity sensors, all manufactured by Pepperl+Fuchs Group, Germany, and specified as usable to SIL3, according to IEC 61508:

SJ 2-SN	NJ 4-12GK-SN	NJ 10-30GK-SN
SJ 3,5-SN	NJ 5-18GK-SN	NJ 15-30GK-SN
SJ 3,5-S1N	NJ 8-18GK-SN	NJ 6S1+U1+N
NJ 2-11-SN	NJ 6-22-SN	NJ 15S+U1+N
NJ 2-11-SN-G	NJ 6-22-SN-G	NJ 20S+U1+N
NJ 2-12GK-SN	NJ 5-30GK-S1N	NJ 40-FP-SN-P1


### 6.1.4 MTL5510 & MTL5510B - Switch/Proximity detector interface

#### 4-channel, digital input and multifunction modules

These digital modules provide solid state output switches in a safe area that respond to switches (inputs) located in a hazardous area. The way they respond - their "mode" - can be configured using a bank of four DIL selector switches accessible through the side of the module - see Figure 6.4.

Model MTL5510 has an one output channel for each input channel and the user can reverse the output phase if necessary to suit the application. Model MTL5510B has more varied modes that can, for example, enable one input to affect multiple outputs or create latched outputs, etc.) The channel output transistors - Ch1/Ch2 and Ch3/Ch4 - share a common terminal and can switch +ve or -ve polarity signals.


Note that series and parallel resistors are required for switch inputs with LFD - see Section 6.1.2 for recommended values.



**Figure 6.3:**  
Top label  
for MTL5510  
& MTL5510B



**Figure 6.4:**  
DIL switches  
for setting  
MODE



Tables 6.1 and 6.2 show details of the modes available and the switch settings required to obtain them.

For ease of access, it is recommended that switches are set to the required mode *before* installation.

Table 6.1 indicates whether the output follows the input, or the output is the reverse or antiphase of the input.

**For example**, in mode 0, o/p 1 = chA; so, if channel A switch is closed, then output 1 will also be closed or short circuit. However, in mode 1, o/p 1 = chA rev., so if channel A switch is closed, then output 1 will be the reverse, i.e. open-circuit.

**Table 6.1 - MTL5510 mode options**

Switch setting				MODE	o/p 1	o/p 2	o/p 3	o/p 4	i/p type
1	2	3	4						
OFF	OFF	OFF	OFF	0	chA	chB	chC	chD	switch
<b>ON</b>	OFF	OFF	OFF	1	chA rev.	chB	chC	chD	
OFF	<b>ON</b>	OFF	OFF	2	chA	chB rev.	chC	chD	
<b>ON</b>	<b>ON</b>	OFF	OFF	3	chA	chB	chC rev.	chD	
OFF	OFF	<b>ON</b>	OFF	4	chA	chB	chC	chD rev.	
<b>ON</b>	OFF	<b>ON</b>	OFF	5	chA rev.	chB	chC rev.	chD	
OFF	<b>ON</b>	<b>ON</b>	OFF	6	chA	chB rev.	chC	chD rev.	
<b>ON</b>	<b>ON</b>	<b>ON</b>	OFF	7	chA rev.	chB rev.	chC rev.	chD rev.	prox. detector + LFD
OFF	OFF	OFF	<b>ON</b>	8	chA	chB	chC	chD	
<b>ON</b>	OFF	OFF	<b>ON</b>	9	chA rev.	chB	chC	chD	
OFF	<b>ON</b>	OFF	<b>ON</b>	10	chA	chB rev.	chC	chD	
<b>ON</b>	<b>ON</b>	OFF	<b>ON</b>	11	chA	chB	chC rev.	chD	
OFF	OFF	<b>ON</b>	<b>ON</b>	12	chA	chB	chC	chD rev.	
<b>ON</b>	OFF	<b>ON</b>	<b>ON</b>	13	chA rev.	chB	chC rev.	chD	
OFF	<b>ON</b>	<b>ON</b>	<b>ON</b>	14	chA	chB rev.	chC	chD rev.	
<b>ON</b>	<b>ON</b>	<b>ON</b>	<b>ON</b>	15	chA rev.	chB rev.	chC rev.	chD rev.	

Table 6.2 shows the **MTL5510B** modes. The logic tables and timing diagrams on the following pages provide more detailed information on these modes.

**Table 6.2 - MTL5510B mode options**

Switch settings				MODE	Function	Equivalent
1	2	3	4			
OFF	OFF	OFF	OFF	0	4-ch switch input (see MTL5510 mode 0)	MTL5510
<b>ON</b>	OFF	OFF	OFF	1	2-ch each channel one input, two outputs	
OFF	<b>ON</b>	OFF	OFF	2	Same as mode 1 with repeat output phase reversed	
<b>ON</b>	<b>ON</b>	OFF	OFF	3	2-ch, 2-pole changeover output	
OFF	OFF	<b>ON</b>	OFF	4	1-ch with line fault output	MTL5014
<b>ON</b>	OFF	<b>ON</b>	OFF	5	As mode 4 with changeover outputs	
OFF	<b>ON</b>	<b>ON</b>	OFF	6	1-ch with start-stop latch	MTL2210B
<b>ON</b>	<b>ON</b>	<b>ON</b>	OFF	7	4-ch switch input, see MTL5510 mode 7	MTL5510
OFF	OFF	OFF	<b>ON</b>	8	4-ch switch input, see MTL5510 mode 8	MTL5510
<b>ON</b>	OFF	OFF	<b>ON</b>	9	2-ch with line fault output	MTL5017
OFF	<b>ON</b>	OFF	<b>ON</b>	10	As mode 9 with LFD changeover	
<b>ON</b>	<b>ON</b>	OFF	<b>ON</b>	11	As mode 10 with channel phase reversed	
OFF	OFF	<b>ON</b>	<b>ON</b>	12	3-ch with normally-open LFD output	
<b>ON</b>	OFF	<b>ON</b>	<b>ON</b>	13	3-ch with normally-closed LFD output	
OFF	<b>ON</b>	<b>ON</b>	<b>ON</b>	14	2-ch monostable, pulse stretcher	
<b>ON</b>	<b>ON</b>	<b>ON</b>	<b>ON</b>	15	4-ch switch input, see MTL5510 mode 15	MTL5510

#### MTL5510 & MTL5510B diagnostics

If an internal fault is detected, all outputs and channel LEDs will turn off and the red Fault LED will turn ON.

## MTL5510B modes

The following logic and timing diagrams are provided to assist the user in understanding the behaviour of the MTL5510B module when a specific **mode** is chosen.

The open switch (—/—) and closed switch (—o—) symbols are used to represent both the input conditions of Ch A, Ch B, Ch C or Ch D and then the output conditions of o/p 1, 2, 3 or 4. Note that in certain modes a Line Fault can cause an override of the output.

### Mode 1

i/p - Ch A		i/p - Ch C	
o/p 1	—/—	—o—	—o—
o/p 2	—o—	—o—	—o—
o/p 3	—/—	—/—	—/—
o/p 4	—o—	—o—	—o—

### How to use these mode tables - examples

The logic tables (right) for Mode 1 represent Ch A controlling outputs 1 & 3, while Ch C controls outputs 2 & 4.

Output 1 & 3 are shown following input Ch A (open or closed) while Outputs 2 & 4 follow input Ch C.

Mode 2 however shows o/p 3 and 4 being in antiphase to their inputs.

### Mode 2

i/p - Ch A		i/p - Ch C	
o/p 1	—/—	—o—	—o—
o/p 2	—o—	—o—	—o—
o/p 3	—o—	—/—	—/—
o/p 4	—/—	—o—	—o—

### Mode 3

i/p - Ch A		i/p - Ch C	
o/p 1	—/—	—o—	—o—
o/p 2	—o—	—/—	—/—
o/p 3	—o—	—o—	—o—
o/p 4	—/—	—/—	—/—

### Mode 4



i/p - Ch A			
No fault	Line fault	No fault	Line fault
o/p 1	—/—	—o—	—o—
o/p 3	—o—	—/—	—/—

### Mode 5

i/p - Ch A			
No fault	Line fault	No fault	Line fault
o/p 1	—/—	—o—	—o—
o/p 2	—o—	—/—	—/—
LFD o/p 3	—o—	—/—	—/—
LFD o/p 4	—/—	—o—	—o—

### Mode 6


i/p Ch C	Non-latching —/—		OR	Latching —o—		
i/p Ch B	Enable —o—			i/p Ch A	Start —/—	Reset —o—
i/p Ch A	—/—	—o—		No effect	Stop —/—	—o—
o/p 1	—o—	—o—		—o—	—/—	—o—
o/p 2	—/—	—/—		—/—	—o—	—/—
o/p 3	—o—	—o—		—o—	—/—	—o—
o/p 4	—/—	—/—		—/—	—o—	—/—




\* i/p Ch A can be open or closed when i/p Ch B opens to stop latch

**MTL5510B modes - continued**

**Mode 9**




**Mode 11**



**Mode 13**

As mode 12 but with LFD o/p 4 reversed




**Mode 14**


This mode provides a two channel pulse stretcher for inputs A and C. Outputs 1 and 2 respond to Ch A, while 3 and 4 respond to Ch C.

Input B (or D) being open or closed affects the input transition and the output polarity as shown in the timing diagrams below.


**Input Ch B (or D) closed**



**Mode 10**




**Mode 12**



When triggered by A (or C) the outputs hold the change of state for a minimum of 1 second or as long as the input (A or C) remains in the same triggered state.

**Input Ch B (or D) open**



### 6.1.5 MTL5511 - Switch/Proximity detector interface


#### Single channel, with line-fault detection

The MTL5511 contains a changeover relay, which enables a safe-area load to be controlled by a switch or proximity detector located in a hazardous-area. When selected, the line-fault detect (LFD) facility detects open or short circuit conditions in the field wiring and also indicates this on the top of the module. **Line-Fault Detect** and **Phase Reversal** for the channel are selected by DIL switches on the side of the module and output is provided by the changeover relay contacts.

See page 18 for LFD and PR switch details. **Channel 1 only** switch settings apply.

For switch sensor inputs, with LFD selected, make sure resistors (22kΩ and 680Ω) are fitted.

**Note:** For reliable, long-term operation the load on the output switching relay should be not less than 50mW, e.g. 10mA at 5V DC.



\* Signal plug HAZ1-3 is required for access to this function


### 6.1.6 MTL5513 - Switch/Proximity detector interface

#### Two-channel, with line-fault detection and phase reversal

The MTL5513 enables two solid-state outputs in the safe area to be controlled by two switches or proximity detectors located in the hazardous area. The Ch1/Ch2 output transistors share a common terminal and can switch +ve or -ve polarity signals. **Line-Fault Detect** and **Phase Reversal** for the channel are selected by DIL switches on the side of the module. LFD indication is provided on the top of the module.

See page 18 for LFD and PR switch details. **Channel 1 & 2** switch settings apply.

For switch sensor inputs, with LFD selected, make sure resistors (22kΩ and 680Ω) are fitted.



**Figure 6.6:**  
**Top label**  
**for MTL5513**

Terminal	Function
1	Input -ve (Ch 1)
2	Input +ve (Ch 1)
3	To earth leakage detector*
4	Input -ve (Ch 2)
5	Input +ve (Ch 2)
6	To earth leakage detector*
10	Output (Ch 2)
11	Output (Ch 1/Ch 2)
12	Output (Ch 1)
13	Supply -ve
14	Supply +ve

\* Signal plug HAZ1-3 is required for access to this function

### 6.1.7 MTL5514 - Switch/Proximity detector interface


#### Single channel, with line-fault detection and phase reversal

The MTL5514 enables a safe-area load to be controlled, through a relay, by a proximity detector or switch located in a hazardous area. Line faults are signalled through a separate relay and indicated on the top of the module. **Line-Fault Detect** and **Phase Reversal** for the channel are selected by DIL switches on the side of the module and output is provided by the changeover relay contacts.

See page 18 for LFD and PR switch details. **Channel 1 only** switch settings apply.

For switch sensor inputs, with LFD selected, make sure resistors (22kΩ and 680Ω) are fitted.

**Note:** For reliable, long-term operation the load on the output switching relays should be not less than 50mW, e.g. 10mA at 5V DC.



**Figure 6.7:**  
Top label  
for MTL5514

Terminal	Function
1	Input -ve
2	Input +ve
3	To earth leakage detector*
7	Normally-closed contact (LFD)
8	Common (LFD)
9	Normally-open contact (LFD)
10	Normally-closed contact (output)
11	Common (output)
12	Normally-open contact (output)
13	Supply -ve
14	Supply +ve

\* Signal plug HAZ1-3 is required for access to this function

### 6.1.8 MTL5516C - Switch/Proximity detector interface


#### Two channel, with line-fault detection

The MTL5516C contains two changeover relays, which enable two safe-area loads to be controlled by switches or proximity detectors located in a hazardous-area. When selected, the line-fault detect (LFD) facility detects open or short circuit conditions in the field wiring and also indicates this on the top of the module. **Line-Fault Detect** and **Phase Reversal** for the channel are selected by DIL switches on the side of the module and output is provided by the changeover relay contacts.

See page 18 for LFD and PR switch details. **Channel 1 & 2** switch settings apply.

For switch sensor inputs, with LFD selected, make sure resistors (22kΩ and 680Ω) are fitted.

**Note:** For reliable, long-term operation the load on the output switching relays should be not less than 50mW, e.g. 10mA at 5V DC.



**Figure 6.8:**  
Top label  
for MTL5516C

Terminal	Function
1	Input -ve (Ch 1)
2	Input +ve (Ch 1)
3	To earth leakage detector*
4	Input -ve (Ch 2)
5	Input +ve (Ch 2)
6	To earth leakage detector*
7	Normally-closed contact (Ch 2)
8	Common (Ch 2)
9	Normally-open contact (Ch 2)
10	Normally-closed contact (Ch 1)
11	Common (Ch 1)
12	Normally-open contact (Ch 1)
13	Supply -ve
14	Supply +ve

\* Signal plug HAZ1-3 is required for access to this function

### 6.1.9 MTL5517 - Switch/Proximity detector interface


#### Two channel, with line-fault detection and phase reversal

The MTL5517 enables two safe-area loads to be controlled, through a relay, by switches or proximity detectors located in a hazardous-area. When selected, the line-fault detect (LFD) is signalled through a separate relay and indicated on the top of the module. **Line-Fault Detect** and **Phase Reversal** for the channel are selected by DIL switches on the side of the module and output is provided by the relay contacts.

See page 18 for LFD and PR switch details. **Channel 1 & 2** switch settings apply.

For switch sensor inputs, with LFD selected, make sure resistors (22kΩ and 680Ω) are fitted.

**Note:** For reliable, long-term operation the load on the output switching relays should be not less than 50mW, e.g. 10mA at 5V DC.



**Figure 6.9:**  
**Top label**  
**for MTL5517**

Terminal	Function
1	Input -ve (Ch 1)
2	Input +ve (Ch 1)
3	To earth leakage detector*
4	Input -ve (Ch 2)
5	Input +ve (Ch 2)
6	To earth leakage detector*
7	Line-fault detection
8	Output (Ch 2)
9	Output (Ch 2)
10	Line-fault detection
11	Output (Ch 1)
12	Output (Ch 1)
13	Supply -ve
14	Supply +ve

\* Signal plug HAZ1-3 is required for access to this function




## 6.2 Digital Output modules

The single channel Digital Output (DO) module range enables on/off devices in a hazardous area to be controlled from the safe area. Some units are loop powered while others enable solid-state switching by providing independent power supplies.

### 6.2.1 MTL5521 - Solenoid Alarm driver

**Single channel, loop powered, IIC**

The MTL5521 is a loop-powered module that enables a device located in the hazardous area (IIC gas group) to be controlled from the safe area. The MTL5521 can drive a certified intrinsically safe low-power load, as well as non-energy-storing simple apparatus such as an LED.



**Figure 6.10:**  
**Top label**  
**for MTL5521**


Terminal	Function
1	Output -ve
2	Output +ve
3	To earth leakage detector*
11	Supply -ve
12	Supply +ve

\*Signal plug HAZ1-3 is required for access to this function

## 6.2.2 MTL5522 - Solenoid Alarm driver

### Single channel, loop powered, IIB

The MTL5522 is a loop-powered module which enables a device located in the hazardous area (IIB gas group) to be controlled from the safe area. The MTL5522 can drive a certified intrinsically safe, low-power load as well as non-energy-storing simple apparatus such as an LED.



**Figure 6.11:**  
Top label  
for MTL5522


Terminal	Function
1	Output -ve
2	Output +ve
3	To earth leakage detector*
11	Supply -ve
12	Supply +ve

\*Signal plug HAZ1-3 is required for access to this function

### 6.2.3 MTL5523 - Solenoid Alarm driver

#### Single channel, with line-fault detection, IIC

The MTL5523 interface controls an on/off device in a hazardous area using a volt-free contact or logic signal in the safe area, and is suitable for driving loads such as solenoids. Line-Fault Detection (LFD) operates independently of the output state and is signalled by a safe-area, solid-state switch output which, when a field line is open or short-circuited, becomes de-energised. Earth-fault detection can be provided by connecting an MTL4220 earth leakage detector to terminal 3.



**Figure 6.12:**  
Top label  
for MTL5523


Terminal	Function
1	Output -ve
2	Output +ve
3	To earth leakage detector*
7	Line fault signal -ve
8	Phase reversal link
9	Phase reversal link
10	Line fault signal +ve
11	Control -ve
12	Control +ve
13	Supply -ve
14	Supply +ve

\*Signal plug HAZ1-3 is required for access to this function

## 6.2.4 MTL5523V - Solenoid Alarm driver

### Single channel, voltage controlled with line-fault detection, IIC

With the MTL5523V interface, an on/off device in a hazardous area can be controlled by a voltage signal in the safe area. It is suitable for driving loads such as solenoids. Line fault detection (LFD), which operates irrespective of the output state, is signalled by a safe-area, solid-state switch which energises if a field line is open or short-circuited. Earth fault detection can be provided by connecting an MTL4220 earth leakage detector to terminal 3. Earth fault detection can be provided by connecting an MTL4220 earth leakage detector to terminal 3.



**Figure 6.13:**  
Top label  
for MTL5523V


Terminal	Function
1	Output -ve
2	Output +ve
3	To earth leakage detector*
7, 8, 9	Line fault signal -ve
10	Line fault signal +ve
11	Control -ve
12	Control +ve
13	Supply -ve
14	Supply +ve

\*Signal plug HAZI-3 is required for access to this function

## 6.2.5 MTL5524 - Solenoid Alarm driver

### Single channel, powered, logic drive with phase reversal

The MTL5524 enables an on/off device in a hazardous area to be controlled by a volt-free contact or logic signal in the safe area. It can drive loads such as solenoids, alarms, LEDs and other low power devices that are certified as intrinsically safe or are classified as non-energy-storing simple apparatus.



**Figure 6.14:**  
**Top label**  
**for MTL5524**


Terminal	Function
1	Output -ve
2	Output +ve
3	To earth leakage detector*
8	Phase reversal link
9	Phase reversal link
11	Control -ve
12	Control +ve
13	Supply -ve
14	Supply +ve

\*Signal plug HAZ1-3 is required for access to this function

## 6.2.6 MTL5525 - Solenoid Alarm driver

**Single channel, low current, loop powered, IIC**

The MTL5525 enables an on/off device in a hazardous area (IIC gas group) to be controlled by a switch or voltage change in the safe area. It can drive loads such as solenoids, alarms, LEDs and other low power devices that are certified as intrinsically safe or are classified as non-energy-storing simple apparatus. Similar in function to the MTL5521, this module provides lower power output and corresponding reduced safety description.



**Figure 6.15:**  
**Top label**  
**for MTL5525**

Terminal	Function
1	Output -ve
2	Output +ve
3	To earth leakage detector*
11	Supply -ve
12	Supply +ve


\*Signal plug HAZ1-3 is required for access to this function

## 6.2.7 MTL5526 - Switch Operated Relay

### Two channel, output

The MTL5526 enables two separate IS circuits in a hazardous area to be relay-contact controlled by two on-off switches or logic signals in a safe area. Applications include the calibration of strain-gauge bridges; changing the polarity (and thereby the tone) of an IS sounder; the testing of IS fire alarms; and the transfer of safe-area signals into an annunciator with IS input terminals not segregated from each other.

The output-relay contacts are certified as non-energy-storing apparatus, and can be connected to any IS circuit without further certification, provided that separate IS circuits are such that they would remain safe if connected together.




**Figure 6.16:**  
Top label  
for MTL5526

Terminal	Function
1	IS relay output 1 (normally open)
2	IS relay output 1 (normally closed)
3	IS relay output 1 (common)
4	IS relay output 2 (common)
5	IS relay output 2 (normally closed)
6	IS relay output 2 (normally open)
8	Relay 1 control +ve
9	Relay 1 control -ve
10	Relay 2 control +ve
11	Relay 2 control -ve
13	Supply -ve
14	Supply +ve

**Table 6.3**  
Switch settings  
for modes

Mode	Function	SW1	SW2	SW3	SW4
Contact/Logic Input	2 ch	Off	On	On	On
	1in2out	On	On	On	On
Loop Powered	2 ch	Off	Off	Off	Off



### 6.3 Pulse and Vibration modules

Single and dual channel modules are available to transfer vibration probe signals from a hazardous area to a safe one. Similarly, pulses from a switch, proximity detector, current pulse transmitter or voltage pulse transmitter, located in the hazardous area, can be safely transferred to the safe area.

#### 6.3.1 MTL5531 - Vibration Transducer Interface

##### Single channel

The MTL5531 repeats a signal from a vibration sensor in a hazardous area, providing an output for a monitoring system in the safe area. The interface is compatible with 3-wire, eddy-current probes and accelerometers or 2-wire current sensors, and selection of the mode is made with a switch located on the side of the module.





Figure 6.17:  
Top label  
for MTL5531

Terminal	Function
1	Transducer power V-
2	Signal
3	Common
11	Signal output -ve
12	Signal output 0V
13	Supply -ve
14	Supply +ve

#### 2-/3-wire transducer setting switch



Mode	SW
2-wire (3.3mA)*	OFF
3-wire (20mA)	ON

\* **Note:** When using 2-wire sensors, ensure that terminals 1 and 2 are linked as shown in the wiring diagram above.




### 6.3.2 MTL5532 - Pulse Isolator

#### Pulse & 4/20mA current outputs

The MTL5532 isolates pulses from a switch, proximity detector, current pulse transmitter or voltage pulse transmitter located in a hazardous area. It is ideal for applications involving high pulse rates and fast response times, by repeating the pulses into the safe area, and the transistors used on the pulse output will switch +ve or -ve polarity signals.

It may be used immediately in simple or legacy mode, or it may be software configured for more specific applications - see next page for either option. With configuration, an analogue output proportional to frequency is available, together with a relay output, which may act as an alarm.


**Note:** For reliable, long-term operation the load on the output switching relay should not be less than 50mW, e.g. 10mA at 5VDC.



**Figure 6.18:**  
**Top label**  
**for MTL5532**

Terminal	Function
1	Common input -ve
2	Switch/proximity input +ve
3	Current pulse input +ve
4	Transmitter supply +ve
5	Voltage pulse input +ve
6	Inhibit input +ve
7	Alarm output
8	Current output -ve
9	Current output +ve
10	Alarm output
11	Pulse output -ve
12	Pulse output +ve
13	Supply -ve
14	Supply +ve

Switches located on the edge of the module define the mode of operation.



SW1	SW2	SW3	SW4
Vsp	Vsp	LFD	Mode

Vsp	SW1	SW2
3V	ON	ON
6V	ON	OFF
12V	OFF	OFF

LFD	SW3
OFF	OFF
ON	ON

### Switch input operation

If switch contacts are used for this Pulse Input (terminals 1 & 2), then series and parallel resistors must be fitted - see Section 6.1.2 for recommended values.

### Simple or Legacy mode - SW4 - OFF

If simple "pulse-in/pulse-out" operation is required or, if a replacement for the earlier MTL5032 pulse isolator is required, then SW4 should be set to OFF. The input switching point voltage (V<sub>sp</sub>) thresholds can then be defined by Switches 1 & 2, and the LFD operation can be set with Switch 3. When Switch 3 is ON, the Alarm output (terminals 11 & 12) become active.

### Configurable mode - SW4 - ON

In this mode, analogue, alarm and pulse outputs are available but the module *must* be software configured to define its operating mode. In this mode, software controls the LFD function and Switch 3 has no effect. Switches 1 & 2 continue to define the switching point threshold (V<sub>sp</sub>). Configuration requires a personal computer, a PCL45USB interface and PCS45 software. See Section 6.9 on page 3855 for details of the configurator.

### Alarm inhibiting

The Inhibit input is provided to inhibit alarm output operation. This facility is useful, for example, during power-up, when pulse rates are below the alarm threshold. When normal operational values are established the inhibit can be disabled. Such a facility is sometimes referred to as a start-up delay. Inhibit is enabled by connecting a switch or proximity detector between terminals 6 and 3. If switch contacts are used for this input, then series and parallel resistors must be fitted - see Section 6.1.2 for recommended values.

### LED indicators


Use the following LED information to understand the module status.

LED	Description
<b>PWR</b> Power (green)	ON - Power OK    OFF - No power or insufficient voltage
<b>O/P</b> Output (yellow)	The LED will follow the pulse output state. If the output is pulsing then the LED brightness will pulse. If the pulsing is rapid or very short, the LED may dim if it is unable to respond to such changes. If the output is high, the LED will be ON.
<b>STS</b> Status (red - flashing)	In legacy mode a line fault will cause the LED to turn ON. In $\mu$ C mode, the LED is programmable to display a line fault or an Alarm trip operation. In the event, it will also indicate a $\mu$ C fault condition.

### 6.3.3 MTL5533 - Vibration Transducer Interface

#### Two channel


The MTL5533 repeats a signal from a vibration sensor in a hazardous area, providing an output for a monitoring system in the safe area. The interface is compatible with 3-wire eddy-current probes and accelerometers or 2-wire current sensors, and selection of the mode for each channel is made with the switches on the side of the module.



**Figure 6.19:**  
Top label  
for MTL5533

Terminal	Function
1	Transducer power V- (Ch1)
2	Signal (Ch1)
3	Common (Ch1)
4	Transducer power V- (Ch2)
5	Signal (Ch2)
6	Common (Ch2)
8	Signal output -ve (Ch2)
9	Signal output 0V (Ch2)
11	Signal output -ve (Ch1)
12	Signal output 0V (Ch1)
13	Supply -ve
14	Supply +ve

#### 2-/3-wire transducer setting switches



Mode	SW
<b>2-wire (3.3mA)</b>	OFF
<b>3-wire (20mA)</b>	ON

**Note:** To enable adequate heat dissipation from the MTL5533 modules, it is recommended that they are installed on the DIN rail with a 10mm space between adjacent units. MTL produce the **MS010 DIN rail module spacer** for this purpose (packs of 5 - see Section 4.3), and these then enable operation in ambient temperatures of up to 50°C


## 6.4 Analogue Input modules

The analogue input (AI) modules support 2-wire or 3-wire 4/20mA or HART transmitters located in a hazardous area; repeating the current in other circuits to drive safe-area loads.

### 6.4.1 MTL5541/MTL5541S - Repeater Power Supply

**Single channel, for 4/20mA HART® for 2- or 3-wire transmitters**

The MTL5541 provides a fully-floating dc supply for energising a conventional 2- or 3-wire 4/20mA transmitter which is located in a hazardous area, and repeats the current in another floating circuit to drive a safe-area load. For HART 2-wire transmitters, the unit allows bi-directional communications signals superimposed on the 4/20mA loop current. Alternatively, the MTL5541S acts as a current sink for a safe-area connection rather than driving a current into the load.




**Figure 6.20:**  
Top label  
for MTL5541

Terminal	Function
1	Current input
2	Transmitter supply +ve
3	Common
10	Output +ve via 220Ω for HART apps.
11	Output -ve (+ve current sink)
12	Output +ve (-ve current sink)
13	Supply -ve
14	Supply +ve

### 6.4.2 MTL5541A/MTL5541AS - Repeater Power Supply

**Single channel, for 4/20mA, HART® for 2- or 3-wire transmitters**

The MTL5541A provides an input for separately powered 4/20mA transmitters and also allows bi-directional transmission of HART communication signals superimposed on the 4/20mA loop current. Alternatively, the MTL5541AS acts as a current sink for a safe-area connection rather than driving a current into the load.






**Figure 6.21:**  
Top labels  
for MTL5541A  
& MTL5541AS

### 6.4.3 MTL5544/MTL5544S - Repeater Power Supply

#### Two channel, for 4/20mA HART® for 2- or 3-wire transmitters

The MTL5544 provides fully-floating dc supplies for energising two conventional 2-wire or 3-wire 4/20mA or HART transmitters located in a hazardous area, and repeats the current in other circuits to drive two safe-area loads. For HART transmitters, the unit allows bi-directional transmission of digital communication signals superimposed on the 4/20mA loop current. Alternatively, the MTL5544S acts as a current sink for a safe-area connection rather than driving a current into the load.




Terminal	Function
1	Ch1 current input
2	Ch1 transmitter supply +ve
3	Ch1 common
4	Ch2 current input
5	Ch2 transmitter supply +ve
6	Ch2 common
7	Ch2 output +ve via 220Ω for HART apps.
8	Ch2 output -ve (+ve current sink)
9	Ch2 output +ve (-ve current sink)
10	Ch1 output +ve via 220Ω for HART apps.
11	Ch1 output -ve (+ve current sink)
12	Ch1 output +ve (-ve current sink)
13	Supply -ve
14	Supply +ve

**Figure 6.22:**  
Top labels  
for MTL5544  
& MTL5544S

The MTL5544 or MTL5544S can also be used to drive two safe-area loads from a single 2-wire transmitter (i.e. 1 in, 2 out) by interconnecting the input channels as shown in the diagram (right).


Note: In this mode the HART data is transferred via channel 1 output only.



### 6.4.4 MTL5544A/MTL5544AS - Current Repeater

#### Two channel, for 4/20mA passive input for HART® transmitters

The MTL5544A provides an input for separately powered 4/20mA transmitters and also allows bi-directional transmission of HART communication signals superimposed on the 4/20mA loop current. Alternatively, the MTL5544AS acts as a current sink for a safe-area connection rather than driving a current into the load.





**Figure 6.23:**  
Top labels  
for MTL5544A  
& MTL5544AS

### 6.4.5 MTL5544D - Repeater Power Supply

**Two channel, for 4/20mA HART® for 2- or 3-wire transmitters, two outputs**

The MTL5544D provides a fully-floating dc supply for energising a conventional 2- or 3-wire 4/20mA transmitter located in a hazardous area, and repeats the current in other circuits to drive two safe-area loads. For HART 2-wire transmitters, the unit allows bi-directional transmission of digital communication signals superimposed on the 4/20mA loop current.



**Figure 6.24:**  
Top label  
for MTL5544D

Terminal	Function
1	Current input
2	Transmitter supply +ve
3	Common
7	Ch2 output +ve via 220Ω for HART apps.
8	Ch2 output -ve
9	Ch2 output +ve
10	Ch1 output +ve via 220Ω for HART apps.
11	Ch1 output -ve
12	Ch1 output +ve
13	Supply -ve
14	Supply +ve

**NOTE**

For correct operation of the module, a suitable load must be present on *both* output channels.

This is of particular importance during testing, commissioning or maintenance activities when the temporary disconnection, or absence, of a load can affect the transfer accuracy of the analogue variable.




## 6.5 Analogue Output modules

The analogue output (AO) modules accept 4/20mA floating signals from safe-area controllers to drive current/pressure converters (or any other load up to 800Ω) in a hazardous area.

### 6.5.1 MTL5546/MTL5546Y - Isolating Driver

#### *Single channel, for 4/20mA HART® valve positioners with line-fault detection*

The MTL5546 accepts a 4/20mA floating signal from a safe-area controller to drive a current/pressure converter (or any other load up to 800Ω) in a hazardous area. For HART valve positioners, the module also permits bi-directional transmission of digital communication signals so that the device can be interrogated either from the operator station or by a hand-held communicator. Process controllers with a readback facility can detect open or short circuits in the field wiring: if these occur, the current taken into the terminals drops to a preset level. The MTL5546Y is very similar to the MTL5546 except that it provides open circuit detection *only* (i.e. no short-circuit detection).




**Figure 6.25:**  
Top labels  
for MTL5546  
& MTL5546Y

## 6.5.2 MTL5549/ MTL5549Y - Isolating Driver

### Two channel, for 4/20mA HART® valve positioners with line-fault detection

The MTL5549 accepts 4/20mA floating signals from safe-area controllers to drive 2 current/pressure converters (or any other load up to 800Ω) in a hazardous area. For HART valve positioners, the module also permits bi-directional transmission of digital communication signals so that the device can be interrogated either from the operator station or by a hand-held communicator. Process controllers with a readback facility can detect open or short circuits in the field wiring: if these occur, the current taken into the terminals drops to a preset level. The MTL5549Y is very similar to the MTL5549 except that it provides open circuit detection only (i.e. no short-circuit detection).



**Figure 6.26:**  
Top labels  
for MTL5549  
& MTL5549Y


## 6.6 Fire and Smoke Interface modules

Interfaces for use with conventional fire and smoke detectors located in hazardous areas.

### 6.6.1 MTL5561 - Fire and Smoke Detector Interface

#### Two channel

The MTL5561 is a loop-powered 2-channel interface for use with conventional fire and smoke detectors located in hazardous areas. In operation, the triggering of a detector causes a corresponding change in the safe-area current. The unit features reverse input polarity protection, while 'no-fail' earth fault detection on either line can be provided by connecting an earth leakage detector to terminal 3 and/or 6.



**Figure 6.27:**  
Top label  
for MTL5561

Terminal	Function
1	Output -ve (Ch 1)
2	Output +ve (Ch 1)
3	Earth leakage detection (Ch 1)
4	Output -ve (Ch 2)
5	Output +ve (Ch 2)
6	Earth leakage detection (Ch 2)
8	Input -ve (Ch 2)
9	Input +ve (Ch 2)
11	Input -ve (Ch 1)
12	Input +ve (Ch 1)

## 6.7 Temperature Input module

These modules accept inputs from low-level dc sources such as thermocouples or RTDs in hazardous areas and converts them into 4/20mA signals to drive safe area loads.

### Early burnout detection (EBD)

When EBD is selected, the resistance of the thermocouple circuit is monitored and an alarm is raised when there is an increase of more than 50Ω. This enables preventative maintenance to be conducted on the field installation before the thermocouple actually breaks.

### Configuration using PCS45/PCL45USB


Use PCS45 software, in conjunction with the PCL45USB serial link, to configure these modules. Instructions are contained within the software. See Section 6.9 on page 56 for further details.

### 6.7.1 MTL5575 - Temperature Converter

#### Single channel, THC or RTD input with alarm

The MTL5575 converts a low-level dc signal from a temperature sensor mounted in a hazardous area into a 4/20mA current for driving a safe-area load. Software selectable features include linearisation, ranging, monitoring, testing and tagging for all thermocouple types and 2, 3 or 4-wire RTDs. (For thermocouple applications the HAZ-CJC plug, on terminals 1–3, includes an integral CJC sensor). Configuration is carried out using a personal computer - see next page. A single alarm output is provided and may be configured for high or low process alarm or to provide notice of early thermocouple failure.

*continued on next page*



**Figure 6.28:**  
Top label  
for MTL5575

All MTL5575 modules are supplied with the following default configuration.

<b>Input type</b>	Type K thermocouple
<b>Linearisation</b>	enabled
<b>Units</b>	°C
<b>CJ Compensation</b>	enabled
<b>Damping value</b>	0 seconds
<b>Smoothing value</b>	0 seconds
<b>Output zero</b>	0°C
<b>Output span</b>	250°C
<b>Tag and description fields</b>	blank
<b>Open circuit alarm</b>	set high (upscale)
<b>Transmitter failure alarm</b>	set low (downscale)
<b>CJ failure alarm</b>	set low (downscale)
<b>Line frequency</b>	50Hz

Use PCS45 software, in conjunction with the PCL45USB serial link, to modify these default values.

#### LED indicators

Use the following LED information to understand the module status.


<b>Status</b>	<b>PWR</b> (green)	<b>STS</b> (yellow)
Power ON	ON	
Insufficient voltage or Power OFF	OFF	
<b>Normal working</b>	ON	
Device failure	FLASH	
Sensor failure/Error	FLASH	
Output relay ON (Trip)	ON	ON
Output relay OFF (Trip)	ON	OFF
Early burnout detection (EBD)	FAST FLASH	

## 6.7.2 MTL5576-RTD - Temperature Converter

### Two channel, RTD/potentiometer input

The MTL5576-RTD converts signals from resistance temperature detectors (RTDs) mounted in a hazardous area, into 4/20mA currents for driving safe-area loads. The MTL5576-RTD is compatible with 2- and 3-wire RTD inputs.

Performance features, including input type and characterisation, ranging, monitoring, testing and tagging are selected using PCS45 software, which is loaded onto a personal computer and connected via the PCL45USB serial link - see Section 6.9.



**Figure 6.29:**  
**Top label**  
**for MTL5576**

Terminal	Function
1	RTD input (Ch1)
2	RTD input (Ch1)
3	3-wire RTD input (Ch1)
4	RTD input (Ch2)
5	RTD input (Ch2)
6	3-wire RTD input (Ch2)
8	Output -ve (Ch2)
9	Output +ve (Ch2)
11	Output -ve (Ch1)
12	Output +ve (Ch1)
13	Supply -ve
14	Supply +ve

### Top label

Use the following LED information to understand the module status.


Status	PWR (green)	FLT (red)	STS (yellow)
Power ON	ON		
Insufficient voltage or Power OFF	OFF		
Communication in progress	FLASH		
<b>Normal working</b>	ON	OFF	OFF
Device failure	ON	ON	
Channel 1 - Sensor failure/Error	ON	FLASH	OFF
Channel 2 - Sensor failure/Error	ON	FLASH	ON

### 6.7.3 MTL5576-THC - Temperature Converter

#### Two channel, mV/THC input

The MTL5576-THC converts low-level dc signals from temperature sensors mounted in a hazardous area, into 4/20mA currents for driving safe-area loads. The hazardous area connections include cold-junction compensation and do not need to be ordered separately.

Performance features, including linearisation for standard thermocouple types, ranging, monitoring, testing and tagging are selected using PCS45 software, which is loaded onto a personal computer and connected via the PCL45USB serial link - see Section 6.9.



**Figure 6.30:**  
**Top label**  
**for MTL5576**

Terminal	Function
1	THC/mV (Ch1)
3	THC/mV (Ch1)
4	THC/mV (Ch2)
6	THC/mV (Ch2)
8	Output -ve (Ch2)
9	Output +ve (Ch2)
11	Output -ve (Ch1)
12	Output +ve (Ch1)
13	Supply -ve
14	Supply +ve

#### Top label


Use the following LED information to understand the module status.

Status	PWR (green)	FLT (red)	STS (yellow)
Power ON	ON		
Insufficient voltage or Power OFF	OFF		
Communication in progress	FLASH		
<b>Normal working</b>	ON	OFF	OFF
Device failure	ON	ON	
Channel 1 - Sensor failure/Error	ON	FLASH	OFF
Channel 2 - Sensor failure/Error	ON	FLASH	ON

### 6.7.4 MTL5581 - mV/Thermocouple Isolator

#### Single channel, mV/THC input for low power signals

The MTL5581 takes a low-level dc signal from a voltage source in a hazardous area, isolates it, and passes it to a receiving instrument located in the safe area. The module is intended for use with thermocouples utilising external cold-junction compensation. A switch enables or disables the safety drive in the event of thermocouple burnout or a cable breakage; a second switch permits the selection of upscale or downscale operation as the application requires.



**Figure 6.31:**  
Top label  
for MTL5581

Terminal	Function
1	THC/mV input -ve
2	THC/mV input +ve
11	Output -ve
12	Output +ve
13	Supply -ve
14	Supply +ve

Please note that the safety drive on the MTL5581 responds to a line breakage (i.e. an open circuit) or a thermocouple burnout. *It does not provide detection of a short circuit.* It can however, when chosen, be set to drive the output either upscale or downscale. These options are selected using the switches located on the side of the module.

Safety drive switches		Line breakage	V <sub>out</sub> value
Sw2 Safety drive	Sw1 Drive direction		
OFF	N/A	NO	V <sub>in</sub> *
OFF	N/A	YES	undetermined
ON	+	NO	V <sub>in</sub> *
ON	+	YES	> +50mV
ON	-	NO	V <sub>in</sub> *
ON	-	YES	< -50mV

\* Within V<sub>in</sub>/V<sub>out</sub> transfer accuracy and drift error as specified in the product datasheet.

#### Safety drive switches



OFF position  
ON position

Sw1	OFF	ON
Drive direction	'+' Upscale	'-' Downscale

Sw2	OFF	ON
Safety drive	OFF	ON




### 6.7.5 MTL5582 - mV/Resistance Isolator

#### Single channel, to repeat RTD signals

The MTL5582 connects to a 2-, 3-, or 4-wire resistance temperature device (RTD) or other resistance located in a hazardous area, isolates it and repeats the resistance to a monitoring system in the safe area. The module is intended typically (but not exclusively) for use with Pt100 3-wire RTDs. Switches enable selection of 2-, 3-, or 4-wire RTD connection. The MTL5582 should be considered as an alternative, non-configurable MTL5575, for use in RTD applications where a resistance input is preferred or needed instead of 4/20mA. The design is notable for its ease of use and repeatability. The number of wires which can be connected on the safe-area side of the unit is independent of the number of wires which can be connected on the hazardous-area side. The module drives upscale in the case of open circuit detection.




**Figure 6.32:**  
Top label  
for MTL5582



Terminal	Function
1	RTD input -ve
3	RTD input +ve
4	3-wire RTD input -ve
5	4-wire RTD input +ve
9	RTD output -ve
10	RTD output +ve
11	RTD output -ve
12	RTD output +ve
13	Supply -ve
14	Supply +ve

**Warning:** Check polarity of terminals used for safe-area connections. Safe-area terminals 9, 10, 11 and 12 are unipolar so it is essential to select a positive terminal on the MTL5582 for connection to the positive of the RTD input card.

#### RTD type selection switches




	Sw 1	Sw 2
2-wire	OFF	ON
3-wire	ON	ON
4-wire	ON	OFF

## 6.8 General modules

These are general purpose modules that have applications associated with the MTL5500 range of modules.


### 6.8.1 MTL5599 - Dummy Isolator

The primary function of the MTL5599, is to provide termination and earthing facilities for unused cable cores from hazardous areas, that can occur, for example, if any MTL5500 Series module has been removed for maintenance purposes.



### 6.8.2 MTL5991 - 24V dc power supply

The MTL5991 provides a convenient source of power for DIN-rail mounted units in locations where a dc supply is not readily available. The wide input power supply range makes this unit universally applicable and the 2A output capability at 24V dc is sufficient to drive a useful number of MTL5500 modules - see table below. See also the MPA5500, in Section 4.2 of this manual, for powering individual modules.




Terminal	Function
1	AC line
2	Earth
3	AC neutral
4	+24V
5	+24V
6	0V
7	0V
8	Do not use

MTL5500 unit	Current Drawn mA ( $V_s=24V$ )	Max. number of units
MTL5501-SR	90	22
MTL5510	40	50
MTL5510B	40	50
MTL5511	25	80
MTL5513	30	66
MTL5514	25	80
MTL5516C	35	57
MTL5517	35	57
MTL5521	90	22
MTL5522	125	16
MTL5523/L/R	100	20
MTL5524/S	100	20
MTL5525	100	20
MTL5526	44	45
MTL5531	96	20
MTL5532	65	30
MTL5533	130	15
MTL5541/S	51	39
MTL5541A/AS	45	44
MTL5544/D/S	96	20
MTL5544A/AS	70	28
MTL5546/C/Y	35	57
MTL5549/C/Y	70	28
MTL5575	50	40
MTL5576	60	33

## 6.9 PCS45/PCL45USB configurator for MTL temperature converters

The PCS45/PCL45USB configurator allows MTL isolating temperature converters to be configured from a standard PC running a Microsoft® Windows® operating system. The configurator comprises PC software provided on a CD (PCS45), and an ATEX certified interfacing link (PCL45USB). Temperature converters can be configured from the safe area, while on-line, and the software allows configurations to be saved to disk and printed out when required.



It is suitable for use with MTL4000, MTL4500, MTL5000 and MTL5500 series products.

### PCL45USB hardware

The PCL45USB provides the interfacing link between the converter module and the PC running the software and connects to the PC using the USB cable provided. The PCL45USB has a built-in cable fitted with a 3.5mm jackplug to connect to the 'Config' socket on MTL4500 and MTL5500 series converters. An adapter cable is also provided to accommodate earlier MTL converters.

### PCS45 Configuration software

The software provided on the CD requires only approximately 20Mb of hard disk space and is compatible with Windows 2000, Windows XP or Windows 7. Ensure that the chosen PC has a CD ROM drive and an available USB port. A local or network printer may also be an advantage.

### Safety

It is not permitted to connect the PCL45USB to any device other than one approved by MTL. Authorisation is valid provided that the converter type is named on the PCL45USB certificate or if the PCL45USB is specified on the converter certificate. Repairs to the PCL45USB are not permitted.

### Setting up

The equipment can be used only in the safe area.

Before plugging in the PCL45USB link to the computer, extract the USB driver files to a known location on your PC. Afterwards, plug in the PCL45USB to the USB port on the PC and wait for it to find the new device. When requested by the computer, show it the location of the driver files so that it can complete the device installation.

Place the PCS45 software CD in the computer's CDROM drive and follow the on-screen instructions to install the software.

The PCL45USB is powered from the data lines and quickly establishes communication after plugging the 3.5mm connector to the device socket.

**Note:** Ensure that the 3.5mm jack plug is fully inserted into the socket of the temperature converter.

The software and its operations manual (INM PCS45) is available on-line at:  
[http://www.mtl-inst.com/product/configuration\\_tools\\_and\\_software/](http://www.mtl-inst.com/product/configuration_tools_and_software/)



## 7 FAULT FINDING AND ROUTINE MAINTENANCE

### WARNING

**On removal, take care that a hazardous-area connector is not laid in a position in which it may inadvertently come into contact with safe-area circuit components.**

### 7.1 Maintenance precautions

Most Codes of Practice for intrinsic safety permit live maintenance on intrinsically safe devices and systems, provided precautions are taken to preserve the integrity of the device or system. During live maintenance of MTL5500 modules, the hazardous-area connectors that plug into the tops of the modules are likely to be removed. Avoid leaving a hazardous-area connector in a position where it may inadvertently contact non-IS circuits that are nearby. Prevent this by providing some form of temporary mechanical method of securing the connector so that it cannot come into contact with the non-IS circuits:

- a) By plugging the connector into an MTL5599 dummy isolator
- b) By using a tie-wrap to constrain the connector in a safe position.

### 7.2 Fault finding

When fault finding, carry out the following steps as far as is necessary:-

#### 7.2.1

Check that all modules with power (PWR) LEDs are ON.

With the MTL5575 & MTL5576 models, a flashing LED indicates alarm or fault conditions, refer to section 8. Note: The LED may also flash during intermediate stages of configuration.

#### 7.2.2

Exchange potentially faulty modules for working units as follows:-

- a) Unplug the hazardous-area connectors, then the safe area connectors.
- b) Unplug any power connectors and remove from DIN rail.
- c) Reverse this procedure to fit a replacement module.

#### 7.2.3

Potentially faulty modules should be tested in workshop conditions, using an appropriate test procedure for the particular module as described in Section 8.

### 7.3 Routine maintenance

Check the general condition of the installation occasionally to make sure that no deterioration has occurred. Carry out the following at least once every two years and more frequently for particularly harsh environments:-

- a) Check that modules are of the types specified in the relevant documentation.
- b) Check that modules and hazardous-area connectors are correctly and legibly tagged, that the connectors are plugged into the matching modules and that the tag details given comply with the relevant documentation.
- c) Check that hazardous- and safe-area connectors are securely plugged into their matching sockets.
- d) Check that all connections to the connectors are properly made.
- e) Check that cables to connectors are of the specified type and rating, are correctly routed and segregated (particularly in MTL enclosures), and are not frayed or otherwise damaged.
- f) Check that cable screens are properly earthed.

Note: It is strongly recommended that only the tests (described in Section 8) and routine maintenance (described here) should be undertaken by users. If a module is faulty, DO NOT attempt to make repairs or modifications as these may affect the intrinsic safety of the module. All faulty units should be returned to the MTL group company or representative from which they were purchased, for repair or replacement.

## 8 BENCH TESTING MODULES

The following methods have been devised to permit the user to perform simple module tests on the bench and confirm basic input to output operation. Field units that do not perform as described below, or modules that have 'unusual' operating behaviour, should be replaced and returned to MTL. Consult individual module wiring diagrams for terminal connections.


Unless stated specifically, the module will require dc power, as if under normal operating conditions.

### 8.1 Digital Input (DI) modules

#### 8.1.1 Modules: MTL 5501-SR, MTL5510, MTL5510B, MTL5511, MTL5513, MTL5514, MTL5516C, MTL5517

##### Input Conditions

1. Connect the appropriate input test circuit to the channel under test (see **Figure 8.1** & **Table 8.1**).
2. For multi-channel modules with LFD, connect a 22kΩ resistor across the other channel input(s) to prevent the signalling of an unwanted open-circuit line fault.
3. Where appropriate test with phase reversal switch in both OFF and ON conditions.



**Figure 8.1:**  
DI input  
test circuit

**Table 8.1**  
Input test  
conditions

Model	Resistor values	Switch - simulation conditions
MTL5501-SR	$R_1 = 10k\Omega$ , $R_2 = 1k4\Omega$	
MTL5510/5510B MTL5511 MTL5513 MTL5514 MTL5516C MTL5517	$R_1 = 22k\Omega$ , $R_2 = 680\Omega$	a) <b>Normal</b> - field switch open b) <b>Normal</b> - field switch closed c) <b>Line Fault</b> - Test for short circuit d) <b>Line Fault</b> - Test for open circuit

##### Output Results

1. For MTL5510 and MTL5510B modules refer to pages 13-15 of this manual.
2. The phase reversal switch will reverse the channel output conditions, but not the LFD.
3. With LFD disabled (OFF) the Status LED should respond as shown in Table 8.2.
4. With LFD disabled (ON) the LEDs and relay should respond as shown in Table 8.3.

**Table 8.2**  
Output test  
results

Input switch positions	Channel contacts		Status LED
	NC	NO	
a	Closed	Open	OFF
b	Open	Closed	ON
c	Open	Closed	ON
d	Closed	Open	OFF


Input switch positions	Channel contacts		LEDs		LFD relay	
	NC	NO	Status	LFD	MTL550x	MTL551x
a	Closed	Open	OFF	OFF	Energised	De-energised
b	Open	Closed	ON	OFF	Energised	De-energised
c	Closed	Open	OFF	ON	De-energised	Energised
d	Closed	Open	OFF	ON	De-energised	Energised

## 8.2 Digital Output (DO) modules

Apply tests per channel.

### 8.2.1 Loop powered: - MTL5521, MTL5522 & MTL5525


**Figure 8.2:**  
Loop powered  
DO test circuit



1. Connect a voltmeter between the + & - output terminals of the module, observing polarity.
2. Apply 24V between the supply terminals ( $V_{s+}$ ,  $V_{s-}$ )
3. The voltmeter should indicate a value between 21.4 and 24 volts
4. Switch off the power to the module
5. Connect an ammeter between the + & - output terminals of the module, observing polarity
6. Apply 24V between the supply terminals ( $V_{s+}$ ,  $V_{s-}$ )
7. The ammeter should indicate no more than 70mA for the MTL5522 and no greater than 48mA for any of the other modules
8. Switch off the power to the module

### 8.2.2 Powered: - MTL5523, MTL5523V & MTL5524


**Figure 8.3:**  
Powered  
DO test circuit



1. Connect a voltmeter between the + & - output terminals of the module, observing polarity
2. Apply 24V between the supply terminals  $V_{s+}$ ,  $V_{s-}$
3. Close the Control switch, or apply the 24V source for the MTL5523V
4. The voltmeter should now indicate a value between 21.4 and 24 volts
5. Switch off the power to the module
6. Connect an ammeter between the + & - output terminals of the module, observing polarity
7. Close the Control switch, or apply the 24V source for the MTL5523V
8. The ammeter should indicate no more than 48mA
9. Switch off the power to the module

### 8.2.3 Relay: - MTL5526

**Figure 8.4:**  
DO test circuit  
for relay type



1. Set in 2-channel mode (SW1 - SW4 respectively to Off, On, On, On)
2. Confirm continuity between NC and Common
3. Apply 24V between the supply terminals  $V_{s+}$ ,  $V_{s-}$
4. Close the Control switch
5. Confirm continuity between NO and Common
6. Switch off the power to the module


### 8.3 Analogue Input (AI) Modules

All of these tests compare the *output* current with the *input* current (A1) over the normal range of operation, and measure the "error current" i.e. the difference - as indicated on A2. Apply these tests *per channel*, as appropriate.

**Ammeter A2** must be capable of handling either polarity. If it is not an auto-ranging instrument, set it to a high range before switch on, then adjust sensitivity to obtain the required reading.

#### 8.3.1 Modules: MTL5541, MTL5544 & MTL5544D

**Figure 8.5:**  
AI test circuit #1




#### Output Measurements

**Note:** Do not connect a voltmeter in circuit to measure V1 until requested in Step 4 below, because current measurement A2 could be affected.

1. Adjust RV1 to vary the current (A1) through the range 4 to 20mA
2. The measured current imbalance (A2) over this range should not exceed  $\pm 20\mu\text{A}$
3. Adjust RV1 for a 20mA reading on A1
4. The voltage V1, across the channel input, should typically be  $>16.5\text{V}$ .

#### 8.3.2 Modules: MTL5541S, MTL5544S & MTL5561

**Figure 8.6:**  
AI test circuit #2  
"o/p sinking"



#### Output Measurements


**Note:** Do not connect a voltmeter in circuit to measure V1 until requested in Step 4 below, because current measurement A2 could be affected. Set A2 range to

1. Adjust RV1 to vary the current (A1) through the range 4 to 20mA.
2. The measured current imbalance (A2) over this range for the MTL5541S and the MTL5544S should not exceed  $\pm 20\mu\text{A}$ . For the MTL5561 the imbalance should not exceed  $\pm 400\mu\text{A}$ .
3. Adjust RV1 for a 20mA reading on A1
4. The voltage V1, across the channel input, should typically be  $>16.5\text{V}$ .



### 8.3.3 Modules: MTL5541A & MTL5544A

**Figure 8.7:**  
AI test circuit #3  
"active i/p"




#### Output Measurements

1. Adjust RV1 to vary the current (A1) through the range 4 to 20mA.
2. The measured current imbalance (A2) over this range should not exceed  $\pm 20\mu\text{A}$

### 8.3.4 Modules: MTL5541AS & MTL5544AS

**Figure 8.8:**  
AI test circuit #4  
"active i/p -  
o/p sinking"




#### Output Measurements

1. Adjust RV1 to vary the current (A1) through the range 4 to 20mA.
- 8.3.5 The measured current imbalance (A2) over this range should not exceed  $\pm 20\mu\text{A}$

### 8.3.6 Module: MTL5581

**Figure 8.9:**  
AI test circuit #5  
"mV input"




Note: V1 should be capable of measurement to within  $1\mu\text{V}$ .

#### Output Measurements

1. With the LINK connected, vary output V2 between 0 and 50mV using RV1. V1 should show  $<50\mu\text{V}$  variation. (Note: Safety Drive can be ON or OFF)
2. With the LINK disconnected and Safety Drive ON, V2 should drive to  $>+50\text{mV}$  with the switch set to '+', or  $<-50\text{mV}$  with the switch set to '-'.

### 8.3.7 Module: MTL5582

**Figure 8.10:**  
AI test circuit #5  
"Resistance input"



#### Output Measurements

1. Set Sw1 & Sw2 to ON for 3-wire operation. Set the resistance box to any value between 10 and  $400\Omega$  and switch on power supply.
2. The green PWR LED should go to a steady state after initially flashing. If the flashing does not stop after 5 seconds then either the setup wiring is faulty or the unit is faulty.
3. Vary the resistance box setting between 10 and  $400\Omega$  and confirm the output voltage varies.
4. Short circuit the input and check that the output voltage is  $\leq 51.6\text{mV}$  after 5 seconds.
5. Open circuit the input and check that the output voltage is  $\leq 2.071\text{V}$  after 5 seconds and that the green PWR LED is flashing.
6. Set the input resistance to  $200\Omega$  and check that the output voltage settles to  $1.0\text{V} \pm 32\text{mV}$

## 8.4 Analogue Output (AO) Modules


The test compares the output current with the input current over the normal range of operation.

### 8.4.1 Modules: All variants

#### Input Conditions

The chosen "load" resistor can be any value between 100 and 800 $\Omega$ .

**Figure 8.11:**  
**AO test circuit**



#### Output Measurements

1. Adjust the current source to vary the current (A1) through the range 4 to 20mA.
2. The measured current imbalance (A2) over this range should not exceed  $\pm 20\mu\text{A}$ .

## 8.5 Testing the functioning of other modules

Simple tests to verify their basic operation can be devised for other modules (e.g. temperature, pulse, vibration, etc). If any assistance is required for the testing of a particular module, please contact the technical support department at MTL for advice.

## 9 APPLICATIONS INVOLVING ZONE 2 AND/OR ZONE 22 HAZARDOUS AREAS

**IMPORTANT:** See page iv at the front of this manual for important additional information regarding the use of these products in countries governed by the ATEX Directive.

The European Community permits Category 3G equipment, such as the MTL5500 Series, to be installed in, or connected to, Zone 2 flammable atmospheres provided it meets the requirements of the ATEX Directive.

MTL5500 Category 3 products have been designed to meet, and carry approval markings for, Ex nL and/or Ex nA. Edition 5 of IEC 60079-11 has introduced the level of protection Ex ic, which is very similar to protection type Ex nL, defined in EN 60079-15, because they are both energy-limited concepts.

(Note: The IEC standards are considering Equipment Protection Level [EPL] marking but at this stage this will not be introduced on MTL products. The situation will be reviewed as the standard writing process becomes more definitive.)

In general, meeting the relevant requirements of the appropriate European (CENELEC) standards is considered the most appropriate method of demonstrating compliance with the ATEX directive. However, MTL often has its products approved by other national bodies, such as FM and CSA and, because national, European, and international standards are converging, it is generally possible to use other national approvals as supporting evidence for the ATEX Technical File.

In the context of this document, Zone 2 (Division 2) and Zone 22 hazardous areas are those that may become potentially explosive through the presence of flammable gases, vapours and dusts for periods of up to 10 hours per year. It is recommended that the current version of the standards is consulted for detailed information on the requirements applicable to the particular installation.

As a consequence of their IS approvals, MTL5500 products *may also be connected into Zone 22 hazardous areas*. Consult individual module approvals for further details.

Unless otherwise specified, the following ambient conditions apply:

Ambient Temperature range	-20°C to +60°C
Pollution Degree 2	(See EN 61010-1)
Measurement Category II	(See EN 61010-1)

### 9.1 Enclosure

EN 60079-15 specifies the minimum required degree of protection to be IP54, but generally this is provided by the external enclosure in which the product is mounted.

The user must refer to the specific certificates relating to the products being installed within the hazardous area to check that all special conditions of safe use have been complied with.

**This page left blank intentionally**

**MTL Instruments Pty Limited**

9 /12 Billabong Street  
Stafford  
Queensland 4053  
Australia  
Tel: + 61 1300 308 374 Fax: + 61 1300 308 463  
E-mail: enquiries@mtlaus.com.au

**Cooper Electric (Shanghai) Co. Ltd.**

Room 2001, China Life Tower  
16 Chao Yang Men Wai Street  
Chao Yang District, Beijing  
China 100020  
Tel: + 86 10 5980 0288 Fax: + 86 10 8562 5725  
E-mail: bjsales@mtl-inst.cn

**MTL Instruments sarl**

Les Carrés du Parc  
10 rue des Rosiéristes  
69410 Champagne au Mont d'Or  
France  
Tel: +33 (0)4 78 64 98 32 Fax: +33 (0)4 78 35 79 41  
E-mail: info@mtl-inst.fr

**MTL Instruments GmbH**

An der Gumpgesbrücke 17  
D-41564 Kaarst  
Germany  
Tel: +49 (0)2131 718930 Fax: +49 (0)2131 7189333  
E-mail: info@mtl.de

**MTL India**

No. 36, Nehru Street  
Off Old Mahabalipuram Road  
Sholinganallur  
Chennai - 600 119  
India  
Tel: + 91 (0)44 24501660/24501857 Fax: + 91 (0)44 24501463  
E-mail: sales@mtlindia.com

**MTL Italia srl**

Via Cantù 11  
I - 20092 Cinisello Balsamo MI  
Italy  
Tel: +39 (0)2 61802011 Fax: +39 (0)2 61294560  
E-mail: info@mtl-inst.it

**Cooper Crouse-Hinds Japan KK**

MT Building 3F  
2-7-5 Shiba Daimon  
Minato-ku Tokyo  
Japan 105-0012  
Tel: +81 (0)3 6430 3128 Fax: +81 (0)3 6430 3129  
E-mail: info@cooperindustries.jp

**Cooper Crouse-Hinds Korea**

12F, Vision Tower  
707-2 Yeoksam-dong, Gangnam-gu  
Seoul 135-080  
South Korea  
Tel: +82 2 3484 6795 Fax: +82 2 3484 6778  
E-mail: MTLKorea-enquiry@cooperindustries.com

**MTL Instruments BV**

MTL Instruments BV  
Terheijdensweg 465  
4825BK Breda  
The Netherlands  
Tel: +31(0)76 7505360 Fax: +31(0)76 7505370  
E-mail: mtl.benelux@cooperindustries.com

**Cooper Crouse-Hinds Pte Ltd.**

No.2 Serangoon North Avenue 5  
#06-01 Fu Yu Building  
Singapore 554911  
Tel: +65 6 487 7887 Fax: +65 6 487 7997  
E-mail: sales.mtlsing@cooperindustries.com

**MTL Instruments**

Villa No. 4, Sector 2-17, Street 6  
PO Box 53234,  
Abu Dhabi, UAE  
Tel: +971 2 446 6840 Fax: +971 2 446 6841  
E-mail: mtlgulf@mtl-inst.com

**Measurement Technology Limited**

Great Marlings, Butterfield, Luton, Beds  
England LU2 8DL  
Tel: +44 (0)1582 723633 Fax: +44 (0)1582 422283  
E-mail: enquiry@mtl-inst.com

**Cooper Crouse-Hinds MTL Inc**

3413 N. Sam Houston Parkway W.  
Suite 210  
Houston TX 77086  
USA  
Tel: +1 281 571 8065 Fax: +1 281 571 8069  
E-mail: csinfo@mtl-inst.com

